

# **HSPICE<sup>®</sup>**

## **Quick Reference Guide**

---

Version X-2005.09, September 2005

**SYNOPTSYS<sup>®</sup>**

# Copyright Notice and Proprietary Information

Copyright © 2005 Synopsys, Inc. All rights reserved. This software and documentation contain confidential and proprietary information that is the property of Synopsys, Inc. The software and documentation are furnished under a license agreement and may be used or copied only in accordance with the terms of the license agreement. No part of the software and documentation may be reproduced, transmitted, or translated, in any form or by any means, electronic, mechanical, manual, optical, or otherwise, without prior written permission of Synopsys, Inc., or as expressly provided by the license agreement.

## Right to Copy Documentation

The license agreement with Synopsys permits licensee to make copies of the documentation for its internal use only. Each copy shall include all copyrights, trademarks, service marks, and proprietary rights notices, if any. Licensee must assign sequential numbers to all copies. These copies shall contain the following legend on the cover page:

"This document is duplicated with the permission of Synopsys, Inc., for the exclusive use of \_\_\_\_\_ and its employees. This is copy number \_\_\_\_\_."

## Destination Control Statement

All technical data contained in this publication is subject to the export control laws of the United States of America. Disclosure to nationals of other countries contrary to United States law is prohibited. It is the reader's responsibility to determine the applicable regulations and to comply with them.

## Disclaimer

SYNOPSIS, INC., AND ITS LICENSORS MAKE NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO THIS MATERIAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

## Registered Trademarks (®)

Synopsys, AMPS, Arcadia, C Level Design, C2HDL, C2V, C2VHDL, Cadabra, Calaveras Algorithm, CATS, CRITIC, CSim, Design Compiler, DesignPower, DesignWare, EPIC, Formality, HSiM, HSPICE, Hypermodel, iN-Phase, in-Sync, Leda, MAST, Meta, Meta-Software, ModelTools, NanoSim, OpenVera, PathMill, Photolynx, Physical Compiler, PowerMill, PrimeTime, RailMill, RapidScript, Saber, SiVL, SNUG, SolvNet, Superlog, System Compiler, Testify, TetraMAX, TimeMill, TMA, VCS, Vera, and Virtual Stepper are registered trademarks of Synopsys, Inc.

## Trademarks (™)

Active Parasitics, AFGen, Apollo, Apollo II, Apollo-DPII, Apollo-GA, ApolloGAI, Astro, Astro-Rail, Astro-Xtalk, Aurora, AvanTestchip, AvanWaves, BCView, Behavioral Compiler, BOA, BRT, Cedar, ChipPlanner, Circuit Analysis, Columbia, Columbia-CE, Comet 3D, Cosmos, CosmosEnterprise, CosmosLE, CosmosScope, CosmosSE, Cyclinelink, Davinci, DC Expert, DC Expert Plus, DC Professional, DC Ultra, DC Ultra Plus, Design Advisor, Design Analyzer, Design Vision, DesignerHDL, DesignTime, DFM-Workbench, Direct RTL, Direct Silicon Access, Discovery, DW8051, DWPCI, Dynamic-Macromodeling, Dynamic Model Switcher, ECL Compiler, ECO Compiler, EDAnavigator, Encore, Encore PQ, Evaccess, ExpressModel, Floorplan Manager, Formal Model Checker, FoundryModel, FPGA Compiler II, FPGA Express, Frame Compiler, Galaxy, Gatran, HANEX, HDL Advisor, HDL Compiler, Hercules, Hercules-Explorer, Hercules-II, Hierarchical Optimization Technology, High Performance Option, HotPlace, HSiMplus, HSPICE-Link, iN-Tandem, Integrator, Interactive Waveform Viewer, i-Virtual Stepper, Jupiter, Jupiter-DP, JupiterXT, JupiterXT-ASIC, JvXtreme, Liberty, Libra-Passport, Library Compiler, Libra-Visa, Magellan, Mars, Mars-Rail, Mars-Xtalk, Medici, Metacapture, Metacircuit, Metamanager, Metamixsim, Milkyway, ModelSource, Module Compiler, MS-3200, MS-3400, Nova Product Family, Nova-ExploreRTL, Nova-Trans, Nova-VeriLint, Nova-VHDLint, Optimum Silicon, Orion\_ec, Parasitic View, Passport, Planet, Planet-PL, Planet-RTL, Polaris, Polaris-CBS, Polaris-MT, Power Compiler, PowerCODE, PowerGate, ProFPGA, ProGen, Prospector, Protocol Compiler, PSMGen, Raphael, Raphael-NES, RoadRunner, RTL Analyzer, Saturn, ScanBand, Schematic Compiler, Scirocco, Scirocco-i, Shadow Debugger, Silicon Blueprint, Silicon Early Access, SinglePass-SoC, Smart Extraction, SmartLicense, SmartModel Library, Softwire, Source-Level Design, Star, Star-DC, Star-MS, Star-MTB, Star-Power, Star-Rail, Star-RC, Star-RCXT, Star-Sim, Star-SimXT, Star-Time, Star-XP, SWIFT, Taurus, TimeSlice, Time Tracker, Timing Annotator, TopoPlace, TopoRoute, Trace-On-Demand, True-Hspice, TSUPREM-4, TymeWare, VCS Express, VCSi, Venus, Verification Portal, VFormal, VHDL Compiler, VHDL System Simulator, VirSim, and VMC are trademarks of Synopsys, Inc.

## Service Marks (sm)

MAP-in, SVP Café, and TAP-in are service marks of Synopsys, Inc.

SystemC is a trademark of the Open SystemC Initiative and is used under license.

ARM and AMBA are registered trademarks of ARM Limited.

All other product or company names may be trademarks of their respective owners.

# **HSPICE Quick Reference Guide**

## Table of Contents

---

Introduction	1
Input and Output Files	2
Behavior Macromodeling	5
Controlling Input	22
Analyzing Data	46
Optimizing Data	63
Output Format	66

---



---

# Introduction

This Quick Reference Guide is a condensed version of the *HSPICE Simulation and Analysis User Guide*, *HSPICE Applications Manual*, and *HSPICE Command Reference*. For more specific details and examples refer to the relevant manual.

---

## Syntax Notation

xxx, yyy, zzz	Arbitrary alphanumeric strings
< ... >	Optional data fields are enclosed in angle brackets < >. All other symbols and punctuation are required.
UPPERCASE	Keywords, parameter names, etc. are represented in uppercase.
lowercase	Variables; should be replaced with a numeric or symbolic value.
...	Any number of parameters of the form shown can be entered.
+	Continuation of the preceding line.

The meaning of a parameter may depend on its location in the statement. Be sure that a complete set of parameters is entered in the correct sequence before running the simulation.

---

## Common Abbreviations

Å	Angstrom
amp	ampere
cm	centimeter
deg	degree Centigrade (unless specified as Kelvin)
ev	electron volt
F	farad
H	Henry
m	meter
s	second
V	volt

---

# Input and Output Files

---

General Form	<i>/usr/george/mydesign.sp</i>
<i>/usr/george/</i>	The design path.
<i>mydesign</i>	The design name.
<i>mydesign</i>	The design root.
<i>tr0</i>	The suffix.

---

## File Name Suffix

X increments for each **.TEMP** or **.ALTER**. X can be one of the characters 0-9999.

Input:

input netlist .sp  
design .cfg  
configuration

Output (X is alter number, usually 0)  
(N is the statement number in one netlist, starting at 0).

graph data .trX (transient analysis)  
.swX (dc sweep)  
.acX (ac analysis)  
.mtX (tran Measure)  
.msX (dc Measure)  
.maX (ac Measure)  
.pwIN\_trX (from .STIM <TRAN> PWL)  
.datN\_trX (from .STIM TRAN DATA)  
.datN\_acX (from .STIM AC DATA)  
.datN\_swX (from .STIM DC DATA)  
.vecN\_trX (from .STIM <TRAN> VEC)

hardcopy data .grX (from .GRAPH)

---

## Input Netlist File

For a complete description of HSPICE installation, system configuration, setup and basic operation, please refer to the *HSPICE Simulation and Analysis User Guide*. HSPICE now accepts input line lengths of 1024 characters.

## Sample Input Netlist File Structure

<b>.TITLE</b>	Implicit first line; becomes input netlist file title.
<b>* or \$</b>	Comments to describe the circuit.
<b>.OPTION</b>	Set conditions for simulation analysis.
<b>&lt;.TRAN&gt; &lt;.AC&gt;</b>	
<b>&lt;.DC&gt; &lt;.OP&gt;</b>	
<b>.TEMPERATURE</b>	Sets the circuit temperatures for the entire circuit simulation.
<b>.PRINT/.PLOT/ .GRAPH/.PROBE</b>	Sets print, plot, graph, and probe variables.
<b>.IC or .NODESET</b>	Sets input state; can also be put in initial conditions.
<b>SOURCES</b>	Sets input stimulus.
<b>NETLIST</b>	Circuit description.
<b>.MACRO libraries</b>	<b>.LIBRARY</b> and <b>.INC</b> .
<b>&lt;.PROTECT&gt;</b>	Suppresses the printout of the text from the list file.
<b>&lt;.UNPROTECT&gt;</b>	Restores output printback.
<b>.ALTER</b>	Sequence for inline case analysis.
<b>.PARAMETER</b>	Defines a parameter.
<b>.END</b>	Terminates any ALTERs and the simulation.

---

## Numeric Scale Factors

A number may be an integer, a floating point number, an integer or floating point number followed by an integer exponent, or an integer or floating point number followed by one of the scale factors listed below.

A	=1e-18
F	=1e-15
P	=1e-12
N	=1e-9

U	=1e-6
M	=1e-3
K	=1e3
MEG (or X)	=1e6
MI	=25.4e6
G	=1e9

---

## Algebraic Expressions

In addition to simple arithmetic operations (+, -, \*, /), the following quoted string functions may be used:

sin(x)	sinh(x)	abs(x)	cos(x)	cosh(x)
min(x,y)	tan(x)	tanh(x)	max(x,y)	atan(x)
sqrt(x)	exp(x)	db(x)	log(x)	log10(x)
pwr(x,y)	pow(x,y)			
or	or			
pwr $x^{**}y$	pow $x^{**}y$			

## Algebraic Expressions as Input

---

General Form	'algebraic expression'
--------------	------------------------

---

Either single ( ' ') or double ( " ") quotes may be used.

## Algebraic Expressions as Output

---

General Form	PAR ('algebraic expression')
--------------	------------------------------

---

The left and right parentheses are mandatory.

## Equation Constants

$\epsilon_0$	Vacuum permittivity=8.854e-12 F/m
$\epsilon_{ox}$	3.453143e-11 F/m
$\epsilon_{si}$	1.0359e-10 F/m dielectric constant of silicon
f	Frequency
k	1.38062e-23 - Boltzmann's constant
q	1.60212e-19 - Electron charge
t	Temperature in degrees Kelvin
$\Delta t$	t - tnom



tnom	Nominal temperature in degrees Kelvin (user-input in degrees C). $T_{nom} = 273.15 + TNOM$
vt(t)	$k \cdot t/q$ Thermal voltage
vt(tnom)	$k \cdot t_{nom}/q$ Thermal voltage

---

## Behavior Macromodeling

HSPICE performs the following types of behavioral modeling.

---

### Subcircuit/Macros

#### **.SUBCKT or .MACRO Statement**

---

General Form	<b>.SUBCKT</b> subnam n1 <n2 n3 ...> + <parnam=val ...>
Or	<b>.MACRO</b> subnam n1 <n2 n3 ...> + <parnam=val ...>

---

n1 ...	Node numbers for external reference
parnam	A parameter name set to a value or another parameter
subnam	Reference name for the subcircuit model call

See “.SUBCKT” or “.MACRO” in the *HSPICE Command Reference*.

#### **.ENDS or .EOM Statement**

---

General Form	<b>.ENDS</b> <SUBNAM>
Or	<b>.EOM</b> <SUBNAM>

See “.ENDS” or “.EOM” in the *HSPICE Command Reference*.

### Subcircuit Calls

---

General Form	Xyyy n1 <n2 n3 ...> subnam + <parnam=val ...> <M=val>
M	Multiplier
n1 ...	Node names for external reference
parnam	A parameter name set to a value for use only in the subcircuit

subnam      Subcircuit model reference name

Xyyy        Subcircuit element name

See “Subcircuit Call Statement” in the *HSPICE Simulation and Analysis User Guide*.

---

## Voltage and Current Controlled Elements

HSPICE supports the following voltage and current controlled elements. For detailed information, see “Voltage and Current Controlled Elements” in the *HSPICE Simulation and Analysis User Guide*.

### E Elements

#### Voltage Controlled Voltage Source—VCVS

##### Linear

---

General Form	<code>Exxx n+ n- &lt;VCVS&gt; in+ in- gain</code> <code>+ &lt;MAX=val&gt; &lt;MIN=val&gt; &lt;SCALE=val&gt;</code> <code>+ &lt;TC1=val&gt; &lt;TC2=val&gt;&lt;ABS=1&gt;</code> <code>+ &lt;IC=val&gt;</code>
--------------	---

---

##### Polynomial

---

General Form	<code>Exxx n+ n- &lt;VCVS&gt; POLY(NDIM) in1+</code> <code>+ in1- ... inndim+ inndim-</code> <code>+ &lt;TC1=val&gt; &lt;TC2=val&gt; &lt;SCALE=val&gt;</code> <code>+ &lt;MAX=val&gt; &lt;MIN=val&gt; &lt;ABS=1&gt;</code> <code>+ p0 &lt;p1...&gt; &lt;IC=val&gt;</code>
--------------	---

---

##### Piecewise Linear

---

General Form	<code>Exxx n+ n- &lt;VCVS&gt; PWL(1) in+</code> <code>+ in- &lt;DELTA=val&gt; &lt;SCALE=val&gt;</code> <code>+ &lt;TC1=val&gt; &lt;TC2=val&gt; x1,y1</code> <code>+ x2,y2 ... x100,y100</code> <code>+ &lt;IC=val&gt;</code>
--------------	--

---

## Multi-Input Gates

---

General Form	<code>Exxx n+ n- &lt;VCVS&gt; gatetype(k)</code> <code>+ in1+ in1- ... inj+ inj-</code> <code>+ &lt;DELTA=val&gt; &lt;TC1=val&gt;</code> <code>+ &lt;TC2=val&gt; &lt;SCALE=val&gt;</code> <code>+ x1,y1 ... x100,y100</code> <code>+ &lt;IC=val&gt;</code>
--------------	---

---

## Delay Element

---

General Form	<code>Exxx n+ n- &lt;VCVS&gt; DELAY in+</code> <code>+ in- TD=val &lt;SCALE=val&gt;</code> <code>+ &lt;TC1=val&gt; &lt;TC2=val&gt;</code> <code>+ &lt;NPDELAY=val&gt;</code>
--------------	---

---

See “Voltage-Controlled Voltage Source (VCVS)” in the *HSPICE Simulation and Analysis User Guide*.

## Behavioral Voltage Source

---

General Form	<code>Exxx n+ n- VOL='equation'</code> <code>+ &lt;MAX=val&gt; &lt;MIN=val&gt;</code>
--------------	--

---

See “Voltage and Current Controlled Elements” in the *HSPICE Simulation and Analysis User Guide*.

## Ideal Op-Amp

---

General Form	<code>Exxx n+ n- OPAMP in+ in-</code>
--------------	---------------------------------------

---

See “Ideal Op-Amp” in the *HSPICE Simulation and Analysis User Guide*.

## Ideal Transformer

---

General Form	<code>Exxx n+ n- TRANSFORMER in+ in- k</code>
--------------	---

---

See “Ideal Transformer” in the *HSPICE Simulation and Analysis User Guide*.

## E Element Parameters

Parameter	Description
ABS	Output is absolute value if ABS=1.
DELAY	Keyword for the delay element.
DELTA	Controls the curvature of the piecewise linear corners.

Parameter	Description
Exxx	Voltage-controlled element name.
gain	Voltage gain.
gatetype(k)	Can be AND, NAND, OR, or NOR.
IC	Initial condition.
in +/-	Positive or negative controlling nodes.
k	Ideal transformer turn ratio.
MAX	Maximum output voltage value.
MIN	Minimum output voltage value.
n+/-	Positive or negative node of a controlled element.
NDIM	Number of polynomial dimensions.
NPDELAY	Sets the number of data points to use in delay simulations.
OPAMP	Keyword for an ideal op-amp element.
P0, P1...	Polynomial coefficients.
POLY	Polynomial keyword.
PWL	Piecewise linear function keyword.
SCALE	Element value multiplier.
TC1, TC2	First-order and second-order temperature coefficients.
TD	Time (propagation) delay keyword.
TRANSFORMER	Keyword for an ideal transformer.
VCVS	Keyword for a voltage-controlled voltage source.
x1,...	Controlling voltage across the in+ and in- nodes.
y1,...	Corresponding element values of x.

See “E Element Parameters” in the *HSPICE Simulation and Analysis User Guide*.

## F Elements

### Current Controlled Current Sources—CCCS

#### Linear

---

General Form	$F_{xxx} n+ n- <CCCS> vn1 gain$ $+ <MAX=val> <MIN=val>$ $+ <SCALE=val> <TC1=val>$ $+ <TC2=val> <M=val> <ABS=1>$ $+ <IC=val>$
--------------	--

---

## Polynomial

---

General Form	Fxxx n+ n- <CCCS> POLY(ndim) + vn1 <... vnndim> <MAX=val> + <MIN=val> <TC1=val> + <TC2=val> <SCALE=val> + <M=val> <ABS=1> p0 <p1...> + <IC=val>
--------------	--

---

## Piecewise Linear

---

General Form	Fxxx n+ n- <CCCS> PWL(1) vn1 + <DELTA=val> <SCALE=val> + <TC1=val> <TC2=val> <M=val> + x1,y1 ... x100,y100 + <IC=val>
--------------	---

---

## Multi-Input Gates

---

General Form	Fxxx n+ n- <CCCS> gatetype(k) + vn1, ... vnk <DELTA=val> + <SCALE=val> <TC1=val> + <TC2=val> <M=val> <ABS=1> + x1,y1 ... x100,y100 + <IC=val>
--------------	--

---

## Delay Element

---

General Form	Fxxx n+ n- <CCCS> DELAY vn1 + TD=val <SCALE=val> + <TC1=val> <TC2=val> + NPDELAY=val
--------------	---

---

See “Current-Controlled Current Source (CCCS)” in the *HSPICE Simulation and Analysis User Guide*.

## F Element Parameters

### Parameter Heading

ABS	Output is absolute value if ABS=1.
CCCS	Keyword for current-controlled current source.
DELAY	Keyword for the delay element.
DELTA	Controls the curvature of piecewise linear corners.
Fxxx	Current-controlled current source element name.
gain	Current gain.
gatetype(k)	Can be AND, NAND, OR, or NOR.

## Parameter Heading

IC	Initial condition (estimate).
M	Number of element replications in parallel.
MAX	Maximum output current value.
MIN	Minimum output current value.
n+/-	Positive or negative controlled source connecting nodes.
NDIM	Number of polynomial dimensions. Must be a positive number. Default=one dimension.
NPDELAY	Number of data points to use in delay simulations.
P0, P1...	Polynomial coefficients.
POLY	Polynomial keyword.
PWL	Piecewise linear function keyword.
SCALE	Element value multiplier.
TC1, TC2	First-order and second-order temperature coefficients.
TD	Time (propagation) delay keyword.
vn1...	Names of voltage sources, through which the controlling current flows.
x1,...	Controlling current, through the vn1 source.
y1,...	Corresponding output current values of x.

See “F Element Parameters” in the *HSPICE Simulation and Analysis User Guide*.

## G Elements

### Voltage Controlled Current Source—VCCS

#### Linear

---

General Form	Gxxx n+ n- <VCCS> in+ in- + transconductance <MAX=val> + <MIN=val> <SCALE=val> + <M=val> <TC1=val> <TC2=val> + <ABS=1> <IC=val>
--------------	---

---

## Polynomial

---

General Form	Gxxx n+ n- <VCCS> POLY(NDIM) + in1+ in1- ... + <inndim+ inndim-> MAX=val> + <MIN=val> <SCALE=val> + <M=val> <TC1=val> <TC2=val> + <ABS=1> P0<P1...> <IC=vals>
--------------	--

---

## Piecewise Linear

---

General Form	Gxxx n+ n- <VCCS> PWL(1) in+ + in- <DELTA=val> <SCALE=val> + <M=val> <TC1=val> <TC2=val> + x1,y1 x2,y2 ... x100,y100 + <IC=val> <SMOOTH=val>
Or	Gxxx n+ n- <VCCS> NPWL(1) in+ + in- <DELTA=val> <SCALE=val> + <M=val> <TC1=val><TC2=val> + x1,y1 x2,y2 ... x100,y100 + <IC=val> <SMOOTH=val>
Or	Gxxx n+ n- <VCCS> PPWL(1) in+ + in- <DELTA=val> <SCALE=val> + <M=val> <TC1=val> <TC2=val> + x1,y1 x2,y2 ... x100,y100 + <IC=val> <SMOOTH=val>

---

## Multi-Input Gates

---

General Form	Gxxx n+ n- <VCCS> gatetype(k) + in1+ in1- ... ink+ ink- + <DELTA=val> <TC1=val> + <TC2=val> <SCALE=val> + <M=val> x1,y1 ... + x100,y100<IC=val>
--------------	--

---

## Delay Element

---

General Form	Gxxx n+ n- <VCCS> DELAY in+ + in- TD=val <SCALE=val> + <TC1=val> <TC2=val> + NPDELAY=val
--------------	---

---

See “Voltage-Controlled Current Source (VCCS)” in the *HSPICE Simulation and Analysis User Guide*.

## Behavioral Current Source

---

General Form	Gxxx n+ n- CUR='equation' +<MAX=val> <MIN=val> <M=val> +<SCALE=val>
--------------	---

---

See “Behavioral Current Source” in the *HSPICE Simulation and Analysis User Guide*.

## Voltage Controlled Resistor—VCR

### Linear

---

General Form	Gxxx n+ n- VCR in+ in- + transfactor <MAX=val> + <MIN=val> <SCALE=val> + <M=val> <TC1=val> <TC2=val> + <IC=val>
--------------	---

---

### Polynomial

---

General Form	Gxxx n+ n- VCR POLY(NDIM) in1+ in1- ... <inndim+ inndim-> + <MAX=val> <MIN=val> + <SCALE=val> <M=val> + <TC1=val> <TC2=val> + P0 <P1...> <IC=vals>
--------------	---

---

### Piecewise Linear

---

General Form	Gxxx n+ n- VCR PWL(1) in+ in- + <DELTA=val> <SCALE=val> + <M=val> <TC1=val> <TC2=val> + x1,y1 x2,y2 ... x100,y100 + <IC=val> <SMOOTH=val>
--------------	---

Or	Gxxx n+ n- VCR NPWL(1) in+ in- + <DELTA=val> <SCALE=val> + <M=val> <TC1=val> <TC2=val> + x1,y1 x2,y2 ... x100,y100 + <IC=val> <SMOOTH=val>
----	--

---

Or	Gxxx n+ n- VCR PPWL(1) in+ in- + <DELTA=val> <SCALE=val> + <M=val> <TC1=val> <TC2=val> + x1,y1 x2,y2 ... x100,y100 + <IC=val> <SMOOTH=val>
----	--

---



## Multi-Input Gates

---

General Form	Gxxx n+ n- VCR gatetype(k) + in1+ in1- ... ink+ ink- + <DELTA=val> <TC1=val> + <TC2=val> <SCALE=val> + <M=val> x1,y1 ... x100,y100 + <IC=val>
--------------	--

---

See “Voltage-Controlled Resistor (VCR)” in the *HSPICE Simulation and Analysis User Guide*.

## Voltage Controlled Capacitors—VCCAP

---

General Form	Gxxx n+ n- VCCAP PWL(1) in+ + in- <DELTA=val> + <SCALE=val> <M=val> + <TC1=val> <TC2=val> + x1,y1 x2,y2 ... x100,y100 + <IC=val> <SMOOTH=val>
--------------	--

---

See “Voltage-Controlled Capacitor (VCCAP)” in the *HSPICE Simulation and Analysis Manual*.

## G Element Parameters

### Parameter Description

ABS	Output is absolute value, if ABS=1.
CUR= equation	Current output which flows from n+ to n-.
DELAY	Keyword for the delay element.
DELTA	Controls the curvature of the piecewise linear corners.
Gxxx	Voltage-controlled element name.
gatetype(k)	Can be AND, NAND, OR, or NOR.
IC	Initial condition.
in +/-	Positive or negative controlling nodes.
M	Number of element replications in parallel.
MAX	Maximum current or resistance value.
MIN	Minimum current or resistance value.
n+/-	Positive or negative node of the controlled element.
NDIM	Number of polynomial dimensions.
NPDELAY	Sets the number of data points to use in delay simulations.
NPWL	Models the symmetrical bidirectional switch or transfer gate, NMOS.

**Parameter Description**

p0, p1 ...	Polynomial coefficients.
POLY	Polynomial keyword.
PWL	Piecewise linear function keyword.
PPWL	Models the symmetrical bidirectional switch or transfer gate, PMOS.
SCALE	Element value multiplier.
SMOOTH	For piecewise-linear, dependent-source elements, SMOOTH selects curve smoothing.
TC1,TC2	First- and second-order temperature coefficients.
TD	Time (propagation) delay keyword.
transconductance	Voltage-to-current conversion factor.
transfactor	Voltage-to-resistance conversion factor.
VCCAP	Keyword for voltage-controlled capacitance element.
VCCS	Keyword for voltage-controlled current source.
VCR	Keyword for the voltage controlled resistor element.
x1, ...	Controlling voltage, across the <i>in+</i> and <i>in-</i> nodes.
y1, ...	Corresponding element values of x.

See “G Element Parameters” in the *HSPICE Simulation and Analysis User Guide*.

**H Elements****Current Controlled Voltage Source—CCVS****Linear**


---

General Form	Hxxx <i>n+</i> <i>n-</i> <CCVS> <i>vn1</i> + transresistance <MAX= <i>val</i> > + <MIN= <i>val</i> > <SCALE= <i>val</i> > + <TC1= <i>val</i> ><TC2= <i>val</i> > <ABS=1> + <IC= <i>val</i> >
--------------	--

---

**Polynomial**


---

General Form	Hxxx <i>n+</i> <i>n-</i> <CCVS> POLY( <i>NDIM</i> ) + <i>vn1</i> <... <i>vnndim</i> > <MAX= <i>val</i> > + <MIN= <i>val</i> > <TC1= <i>val</i> > + <TC2= <i>val</i> > <SCALE= <i>val</i> > + <ABS=1> <i>P0</i> < <i>P1</i> ...> <IC= <i>val</i> >
--------------	---

---

## Piecewise Linear

---

General Form	Hxxx n+ n- <CCVS> PWL(1) vn1 + <DELTA=val> <SCALE=val> + <TC1=val> <TC2=val> x1,y1 ... + x100,y100 <IC=val>
--------------	--

---

## Multi-Input Gates

---

General Form	Hxxx n+ n- gatetype(k) + vn1, ... vnk <DELTA=val> + <SCALE=val> <TC1=val> + <TC2=val> x1,y1 ... + x100,y100 <IC=val>
--------------	--

---

## Delay Element

---

General Form	Hxxx n+ n- <CCVS> DELAY vn1 + TD=val <SCALE=val><TC1=val> + <TC2=val> <NPDELAY=val>
--------------	---

---

See “Current-Controlled Voltage Source (CCVS)” in the *HSPICE Simulation and Analysis User Guide*.

## H Element Parameters

Parameter	Description
ABS	Output is absolute value if ABS=1.
CCVS	Keyword for current-controlled voltage source.
DELAY	Keyword for the delay element.
DELTA	Controls the curvature of piecewise linear corners.
gatetype(k)	Can be AND, NAND, OR, or NOR.
Hxxx	Current-controlled voltage source element name.
IC	Initial condition.
MAX	Maximum voltage value.
MIN	Minimum voltage value.
n+/-	Positive or negative controlled source connecting nodes.
NDIM	Number of polynomial dimensions.
NPDELAY	Number of data points to use in delay simulations.
P0, P1...	Polynomial coefficients.
POLY	Polynomial dimension.
PWL	Piecewise linear function keyword.

## Parameter Description

SCALE	Element value multiplier.
TC1, TC2	First-order and second-order temperature coefficients.
TD	Time (propagation) delay keyword.
trans-resistance	Current-to-voltage conversion factor.
vn1...	Names of voltage sources, through which the controlling current flows.
x1,...	Controlling current, through the <i>vn1</i> source.
y1,...	Corresponding output voltage values of <i>x</i> .

See “H Element Parameters” in the *HSPICE Simulation and Analysis User Guide*.

## Op-Amp Element Statement

---

COMP=0	xa1 in- in+ out vcc vee modelname AV=val
Or	
COMP=1	xa1 in- in+ out comp1 comp2 vcc vee modelname AV=val

---

in+	Noninverting input
in-	Inverting input
modelname	Subcircuit reference name
out	Output, single ended
vcc	Positive supply
vee	Negative supply

See “Op-Amp Element Statement Format” in the *HSPICE Applications Manual*.

## Op-Amp .MODEL Statement

---

General Form	<b>.MODEL</b> <i>mname</i> AMP parameter= <i>value</i> ...
--------------	--

---

AMP	Identifies an amplifier model
<i>mname</i>	Model name. Elements reference the model by this name.
parameter	Any model parameter described below
value	Value assigned to a parameter

See “Op-Amp .MODEL Statement Format” in the *HSPICE Applications Manual*.

## P Element

### Ports

---

General Pxxx p n port=*portnumber*  
Form + \$ \*\*\*\* Voltage or Power Information \*\*\*\*\*  
+ <DC *mag*> <AC <*mag* <*phase*>>>  
+ <HBAC <*mag* <*phase*>>> <HB <*mag* <*phase* <*harm*  
+ <*tone* <*modharm* <*modtone*>>>>>>>>  
+ <*transient\_waveform*> <TRANFORHB=[0|1]>  
+ <DCOPEN=[0|1]>  
+ \$ \*\*\*\* Source Impedance Information \*\*\*\*\*  
+ <Z0=*val*> <RDC=*val*> <RAC=*val*>  
+ <RHBAC=*val*> <RHB=*val*> <RTRAN=*val*>  
+ \$ \*\*\*\* Power Switch \*\*\*\*\*  
+ <power=[1|0]>

---

### P Element Parameters

Parameter	Description
port= <i>portnumber</i>	The port number. The ports are numbered sequentially beginning with 1 with no shared port numbers.
<DC <i>mag</i> >	DC voltage or power source value.
<AC < <i>mag</i> < <i>phase</i> >>>	AC voltage or power source value.
<HBAC < <i>mag</i> < <i>phase</i> >>>	(HSPICE RF) HBAC voltage or power source value.
<HB < <i>mag</i> < <i>phase</i> < <i>harm</i> < <i>tone</i> < <i>modharm</i> < <i>modtone</i> >>>>>>>>	(HSPICE RF) HB voltage, current, or power source value. Multiple HB specifications with different harm, tone, modharm, and modtone values are allowed. <i>phase</i> is in degrees <i>harm</i> and <i>tone</i> are indices corresponding to the tones specified in the .HB statement. Indexing starts at 1 (corresponding to the first harmonic of a tone). <i>modtone</i> and <i>modharm</i> specify sources for multi-tone simulation. A source specifies a tone and a harmonic, and up to 1 offset tone and harmonic (modtone for tones and modharm for harmonics). The signal is then described as: $V(\text{or } I) = \text{mag} * \cos(2 * \pi * (\text{harm} * \text{tone} + \text{modharm} * \text{modtone}) * t + \text{phase})$
< <i>transient waveform</i> >	(Transient analysis) Voltage or power source waveform. Any one of waveforms: AM, EXP, PULSE, PWL, SFFM, or SIN. Multiple transient descriptions are not allowed.

Parameter	Description
TRANFORHB=[0 1]	<p>0 (default): The transient description is ignored if an HB value is given or a DC value is given. If no DC or HB value is given and TRANFORHB=0, then HB treats the source as a DC source, and the DC source value is the time=0 value.</p> <p>1: HB analysis uses the transient description if its value is VMRF, SIN, PULSE, PWL, or LFSR. If the type is a non-repeating PWL source, then the time=infinity value is used as a DC source value. To override the global TRANFORHB option, explicitly set TRANFORHB for a voltage or current source.</p>
DCOPEN	<p>Switch for open DC connection when DC <i>mag</i> is not set.</p> <p>0 (default): P element behaves as an impedance termination.</p> <p>1: P element is considered an open circuit in DC operating point analysis. DCOPEN=1 is mainly used in .LIN analysis so the P element will not affect the self-biasing device under test by opening the termination at the operating point.</p>
<z0=val>	<p>(LIN analysis) System impedance used when converting to a power source, inserted in series with the voltage source. Currently, this only supports real impedance.</p> <p>When power=0, z0 defaults to 0.</p> <p>When power=1, z0 defaults to 50 ohms.</p> <p>You can also enter zo=val.</p>
<RDC=val>	(DC analysis) Series resistance (overrides z0).
<RAC=val>	(AC analysis) Series resistance (overrides z0).
<RHBAC=val>	(HSPICE RF HBAC analysis) Series resistance (overrides z0).
<RHB=val>	(HSPICE RF HB analysis) Series resistance (overrides z0).
<RTRAN=val>	(Transient analysis) Series resistance (overrides z0).

Parameter	Description
<power=[0   1   2   W   dbm]>	<p>(HSPICE RF) Power Switch</p> <p>When 0 (default), element treated as a voltage or current source.</p> <p>When 1 or W, element treated as a power source, realized as a voltage source with a series impedance. In this case, the source value is interpreted as RMS available power in units of Watts.</p> <p>When 2 or dbm, element treated as a power source in series with the port impedance. Values are in dbms.</p> <p>You can use this parameter for Transient analysis if the power source is either DC or SIN.</p>

## S Element

### Transmission Line

---

General Form	<p>Sxxx nd1 nd2 ... ndN ndRef</p> <p>+ &lt;MNAME=Smodel_name&gt;</p> <p>+ &lt;FQMODEL=sp_model_name&gt;</p> <p>+ &lt;TYPE=[s   y]&gt; &lt;Zo=[value   vector_value]&gt;</p> <p>+ &lt;FBASE = base_frequency&gt;</p> <p>+ &lt;FMAX=maximum_frequency&gt;</p> <p>+ &lt;PRECFAC=val&gt;</p> <p>+ &lt;DELAYHANDLE=[1   0   ON   OFF]&gt;</p> <p>+ &lt;DELAYFREQ=val&gt;</p> <p>+ &lt;INTERPOLATION=STEP   LINEAR   SPLINE&gt;</p> <p>+ &lt;INTDATTYP =[RI   MA   DBA]&gt;</p> <p>+ &lt;HIGHPASS=val&gt;</p> <p>+ &lt;LOWPASS=val&gt; &lt;MIXEDMODE=[0   1]&gt;</p> <p>+ &lt;DATATYPE=data_string&gt;</p> <p>+ &lt;NOISE=[1   0]&gt; &lt;DTEMP=val&gt;</p>
--------------	---

---

## S Element Parameters

Parameter	Description
nd1 nd2 ... ndN	<i>N</i> terminal nodes.
nd_ref	Reference node.
MNAME	S model name, which is used to refer to an S model.
FQMODEL	.MODEL statement of sp type, which defines the frequency behavior of the S or Y parameter.

Parameter	Description
TYPE	Parameter type: S (scattering) (default) Y (admittance) Z (impedance)
Zo	Characteristic impedance value for the reference line (frequency-independent). For multiple terminals ( $N > 1$ ), HSPICE or HSPICE RF assumes that the characteristic impedance matrix of the reference lines is diagonal, and that you set diagonal values to Zo. To specify more general types of reference lines, use ZoF. The default is 50.
FBASE	The base frequency. This value becomes the base frequency point for the Inverse Fourier Transformation. If you do not set this value, the base frequency is a reciprocal value of the transient period.
FMAX	Maximum frequency use in transient analysis. HSPICE uses the value as the maximum frequency point for Inverse Fourier Transformation.
PRECFCAC	A precondition factor keyword used for the precondition process of the S parameter. A precondition is used to avoid an infinite admittance matrix. The default is 0.75, which is good for most cases.
DELAYHANDLE	Delay handler for transmission-line type parameters. Set DELAYHANDLE to ON (or 1) to turn on the delay handle; set DELAYHANDLE to OFF (or 0) to turn off the delay handle (default).
DELAYFREQ	Delay frequency for transmission-line type parameters. The default is FMAX. If the DELAYHANDLE is set to OFF, but DELAYFREQ is nonzero, HSPICE still simulates the S element in delay mode.
INTERPOLATION	The interpolation method: STEP: piecewise step LINEAR: piecewise linear (default) SPLINE: b-spline curve fit



<b>Parameter</b>	<b>Description</b>
INTDATATYPE	Data type for the linear interpolation of the complex data. RI: real-imaginary based interpolation MA: magnitude-angle based interpolation (default) DBA: dB-angle based interpolation
HIGHPASS	Method to extrapolate higher frequency points. 0: cut off 1: use highest frequency point 2: perform linear extrapolation using the highest 2 points 3: apply the window function to gradually approach the cut-off level (default)
LOWPASS	Method to extrapolate lower frequency points. 0: cut off 1: use the magnitude of the lowest point 2: perform linear extrapolation using the magnitude of the lowest two points
MIXEDMODE	Set to 1 if the parameters are represented in the mixed mode.
DATATYPE	A string used to determine the order of the indices of the mixed-signal incident or reflected vector. The string must be an array of a letter and a number (Xn) where: X = D to indicate a differential term = C to indicate a common term = S to indicate a single (grounded) term n = the port number
NOISE	Activates thermal noise. 1: element generates thermal noise 0 (default): element is considered noiseless
DTEMP	Temperature difference between the element and the circuit. Expressed in °C. The default is 0.0.

---

## Controlling Input

For complete definitions, see the *HSPICE Simulation and Analysis User Guide*, “Specifying Simulation Input and Controls.”

---

### .OPTION Statement

---

General Form	<code>.OPTION opt1 &lt;opt2 opt3 ...&gt;</code>
--------------	---

---

opt1 ...	Specifies any input control options.
----------	--------------------------------------

See “.OPTION” in the *HSPICE Command Reference*.

---

### General Control (I/O) Options

Option	Description
ACCT	Reports job accounting and runtime statistics, at the end of the output listing.
ACOUT	AC output calculation method for the difference in values of magnitude, phase, and decibels for prints and plots.
ALT999, ALT9999	This option is no longer necessary and is ignored because HSPICE accepts any number of <b>.ALTER</b> statements without overwriting files beyond the 36th <b>.ALTER</b> statement.
ALTCC	Enables only reading the input netlist once for multiple <b>.ALTER</b> statements.
ALTCHK	Disables topology checking in elements redefined by the <b>.ALTER</b> statement.
BEEP	BEEP=1 sounds an audible tone when simulation returns a message, such as “info: HSPICE job completed.” BEEP=0 turns off the audible tone.
BINPRINT	Outputs binning parameters of the CMI MOSFET model. Currently available only for Level 57.
BRIEF, NXX	Stops print back of data file until HSPICE or HSPICE RF finds an <b>.OPTION BRIEF = 0</b> , or the <b>.END</b> statement.
CO = x	Sets the number of columns for printout: x can be either 80 (for narrow printout) or 132 (for wide carriage printouts).

<b>Option</b>	<b>Description</b>
INGOLD = x	Specifies the printout data format.
LENNAM = x	Maximum length of names in the printout of operating point analysis results.
LIST	Produces an element summary of the input data to print.
MEASDGT = x	Formats the <b>.MEASURE</b> statement output in both the listing file and the <b>.MEASURE</b> output files ( <i>.ma0</i> , <i>.mt0</i> , <i>.ms0</i> , and so on).
NODE	Prints a node cross reference table.
NOELCK	Bypasses element checking to reduce pre-processing time for very large files.
NOMOD	Suppresses printout of model parameters
NOPAGE	Suppresses page ejects for title headings
NOTOP	Suppresses topology checks to increase speed for pre-processing very large files
NUMDGT = x	Number of significant digits to print for output variable values.
NXX	Same as BRIEF. See BRIEF.
OPFILE = x	Outputs the operating point information to a new file.
OPTLST = x	Outputs additional optimization information: <ul style="list-style-type: none"> <li>0 No information (default).</li> <li>1 Prints parameter, Broyden update, and bisection results information.</li> <li>2 Prints gradient, error, Hessian, and iteration information.</li> <li>3 Prints all of the above, and Jacobian.</li> </ul>
OPTS	Prints the current settings for all control options.
PATHNUM	Prints subcircuit path numbers, instead of path names
PLIM = x	Specifies plot size limits for current and voltage plots.
POSTTOP= <i>n</i>	Outputs instances, up to <i>n</i> levels deep. <b>.OPTION POST</b> saves all nodes, at all levels of hierarchy. <b>.OPTION POSTTOP</b> or <b>.OPTION POSTTOP=1</b> saves only the TOP node. <b>.OPTION POSTTOP=2</b> saves only nodes at the top two levels.

Option	Description
POST_VERSION = x	Sets the post-processing output version with values x=9601, 9007, or 2001.
STATFL	Controls if HSPICE creates a .st0 file. statfl=0 (default) outputs a .st0 file. statfl=1 suppresses the .st0 file.
SEARCH	Search path for libraries and included files.

See “General Control Options” in the *HSPICE Command Reference*.

## CPU Options

Option	Description
CPTIME = x	Maximum CPU time in seconds, allotted for this simulation job.
EPSMIN = x	Smallest number that a computer can add or subtract, a constant value.
EXPMAX = x	Largest exponent that you can use for an exponential, before overflow occurs.
LIMTIM = x	Amount of CPU time reserved to generate prints and plots, if a CPU time limit (CPTIME = x) terminates simulation.

See “CPU Options” in the *HSPICE Simulation and Analysis User Guide*.

## Interface Options

Option	Description
ARTIST = x	ARTIST = 2 enables Cadence Analog Artist interface. Requires a specific license.
CDS, SDA	CDS = 2 produces a Cadence WSF (ASCII format) post-analysis file for Opus™. Requires a specific license.
CSDF	Selects Common Simulation Data Format (Viewlogic-compatible graph data file).
DLENCSDF	How many digits to use with Viewlogic-compatible graph data file format.
MEASOUT	Outputs <b>.MEASURE</b> statement values and sweep parameters into an ASCII file for post-analysis processing using AvanWaves or other analysis tools.

<b>Option</b>	<b>Description</b>
MENTOR = x	MENTOR = 2 enables the Mentor MSPICE-compatible (ASCII) interface. Requires a specific license.
MONTECON	Continues Monte Carlo analysis. Retrieves next random value, even if non-convergence occurs.
POST = x	Stores simulation results for analysis by using AvanWaves interface or other methods. POST = 1 saves results in binary. POST = 2 saves results in ASCII. POST = 3 saves results in New Wave binary format.
PROBE	Limits post-analysis output to only variables specified in <b>.PROBE</b> , <b>.PRINT</b> , <b>.PLOT</b> , and <b>.GRAPH</b> statements.
PSF = x	Specifies if HSPICE or HSPICE RF outputs binary or ASCII data from the Parameter Storage Format.
SDA	Same as CDS. See CDS.
ZUKEN = x	If x is 2, enables Zuken interactive interface. If x is 1 (default), disables this interface.

See “Interface Options” in the *HSPICE Command Reference*.

## Analysis Options

<b>Option</b>	<b>Description</b>
ASPEC	Sets HSPICE or HSPICE RF to ASPEC-compatibility mode.
FFTOUT	Prints 30 harmonic fundamentals, sorted by size, THD, SNR, and SFDR. You can use this option in HSPICE, but not in HSPICE RF.
LIMPTS = x	Number of points to print or plot in AC analysis.
NOISEMINFREQ = x	Specifies the minimum frequency of noise analysis. Default = 1e-5.
PARHIER	Selects parameter-passing rules that control evaluation order of subcircuit parameters.
SPICE	Makes HSPICE compatible with Berkeley SPICE.
SEED	Starting seed for a random-number generator for Monte Carlo analysis.

See “Analysis Options” in the *HSPICE Command Reference*.

## Error Options

Option	Description
BADCHR	Generates a warning when it finds a non-printable character in an input file.
DIAGNOSTIC	Logs negative model conductances.
NOWARN	Suppresses all warning messages, except those generated from statements in <b>.ALTER</b> blocks.
WARNLIMIT = x	Limits how many times certain warnings appear in the output listing. This reduces the output listing file size.

See “Error Options” in the *HSPICE Command Reference*.

## Version Options

Option	Description
H9007	Sets default values for general-control options to correspond to the values for HSPICE Release H9007D.

See “Version Options” in the *HSPICE Command Reference*.

---

## Model Analysis Options

See “Model Analysis Options” in the *HSPICE Command Reference*.

## General Options

Option	Description
DCAP	Selects equations to calculate depletion capacitance for LEVEL 1 or 3 diodes, BJTs.
HIER_SCALE	Defines how HSPICE or HSPICE RF interprets the S parameter as a user-defined parameter or an HSPICE scale parameter.
MODSRH	If MODSRH=1, HSPICE or HSPICE RF does not load or reference a model described in a <b>.MODEL</b> statement, if the netlist does not use that model. This option can shorten simulation run time. Default is MODSRH=0.
SCALE	Element scaling factor.
TNOM	Reference temperature for simulation.

<b>Option</b>	<b>Description</b>
MODMONTE	<p>If MODMONTE=1, then each device receives a different random value for its Monte Carlo parameters.</p> <p>If MODMONTE=0 (default), then each device receives the same random value for its Monte Carlo parameters. HSPICE RF does not support Monte Carlo analysis.</p>

## MOSFET Control Options

<b>Option</b>	<b>Description</b>
CVTOL	Changes the number of numerical integration steps when calculating gate capacitor charge for a MOSFET by using CAPOP = 3.
DEFAD	Default value for MOSFET drain diode area.
DEFAS	Default value for MOSFET source diode area.
DEFLL	Default value for MOSFET channel length.
DEFNRD	Default number of squares for drain resistor on a MOSFET.
DEFNRS	Default number of squares for source resistor on a MOSFET.
DEFPD	Default MOSFET drain diode perimeter.
DEFPS	Default MOSFET source diode perimeter.
DEFW	Default MOSFET channel width.
SCALM	Model scaling factor.
WL	Reverses specified order in the VSIZE MOS element. Default order is length-width; changes order to width-length.
WNFLAG=[0 1]	(BSIM4 models). Used to globally turn on the WNFLAG instance parameter. Local definition takes precedence.

See “MOSFET Control Options” in the *HSPICE Command Reference*.

## Inductor Options

You can use the following inductor options in HSPICE, but not in HSPICE RF:

GENK	Automatically computes second-order mutual inductance for several coupled inductors.
KLIM	Minimum mutual inductance, below which automatic second-order mutual inductance calculation no longer proceeds.

## BJT and Diode Options

EXPLI	Current-explosion model parameter. PN junction characteristics above explosion current are linear.
-------	--

## DC Solution Control Options

Option	Description
ABSH = x	Sets the absolute current change, through voltage-defined branches (voltage sources and inductors).
ABSI = x	Sets the absolute branch current error tolerance in diodes, BJTs, and JFETs during DC and transient analysis.
ABSMOS = x	Current error tolerance (for MOSFET devices) in DC or transient analysis.
ABSTOL = x	ABSTOL is an alias for ABSI. See ABSI.
ABSVDC = x	Sets the absolute minimum voltage for DC and transient analysis.
DI = x	Sets the maximum iteration-to-iteration current change, through voltage-defined branches (voltage sources and inductors).
GDCPATH	Adds conductance to nodes having no DC path to ground.
KCLTEST	Starts KCL (Kirchhoff's Current Law) test.
MAXAMP = x	Sets the maximum current, through voltage-defined branches (voltage sources and inductors).
RELH = x	Relative current tolerance, through voltage-defined branches (voltage sources and inductors).
RELI = x	Relative error/tolerance change, from iteration to iteration. Determines convergence for all currents in diode, BJT, and JFET devices.
RELMOS = x	Sets error tolerance (percent) for drain-to-source current, from iteration to iteration. Determines convergence for currents in MOSFET devices.



<b>Option</b>	<b>Description</b>
RELV = x	Relative error tolerance for voltages.
RELVDC = x	Relative error tolerance for voltages.

See “DC Operating Point, DC Sweep, and Pole/Zero Options” in the *HSPICE Command Reference*.

## Matrix Options

ITL1 = x	Maximum DC iteration limit.
ITL2 = x	Iteration limit for the DC transfer curve.
NOPIV	Prevents HSPICE from automatically switching to pivoting matrix factors.
PIVOT = x	Selects a pivot algorithm.
PIVREF	Pivot reference.
PIVREL = x	Maximum/minimum row/matrix ratio.
PIVTOL = x	Absolute minimum value for which HSPICE or HSPICE RF accepts a matrix entry as a pivot.
SPARSE = x	Same as PIVOT.

## Pole/Zero I/O Options

CAPTAB	Prints table of single-plate node capacitance for diodes, BJTs, MOSFETs, JFETs, and passive capacitors at each operating point.
DCCAP	Generates C-V plots, and prints capacitance values of a circuit (both model and element), during a DC analysis.
OPFILE	The OPFILE option outputs the operating point information to a new file.
VFLOOR = x	Minimum voltage to print in output listing.

## DC Convergence Options

ABSTOL =	ABSTOL is an alias for ABSI. See ABSI.
CAPTAB	Prints table of single-plate node capacitance for diodes, BJTs, MOSFETs, JFETs, and passive capacitors at each operating point.
CONVERGE	Invokes different methods to solve non-convergence problems
CSHDC	The same option as CSHUNT; use only with the CONVERGE option.

DCCAP	Generates C-V plots, and prints capacitance values of a circuit (both model and element), during a DC analysis.
DCFOR = x	Use with DCHOLD and <b>.NODESET</b> to enhance DC convergence.
DCHOLD = x	Use DCFOR and DCHOLD together to initialize a DC analysis.
DCIC = x	DC sweep analysis loads the initial conditions for DC sweep points.
DCON = X	If a circuit cannot converge, HSPICE or HSPICE RF automatically sets DCON = 1.
DCSTEP = x	Converts DC model and element capacitors to a conductance to enhance DC convergence properties.
DCTRAN	DCTRAN is an alias for CONVERGE. See CONVERGE.
DV = x	Maximum iteration-to-iteration voltage change for all circuit nodes in both DC and transient analysis.
GMAX = x	Conductance in parallel with a current source for <b>.IC</b> and <b>.NODESET</b> initialization circuitry.
GMINDC = x	Conductance in parallel to all $p_n$ junctions and all MOSFET nodes for DC analysis.
GRAMP = x	HSPICE sets this value during autoconvergence.
GSHDC	Adds conductance from each node to ground when calculating the DC operating point of the circuit ( <b>.OP</b> ). Default=0.
GSHUNT	Adds conductance from each node to ground. Default=0.
ICSWEEP	Saves current analysis result of parameter or temperature sweep as the starting point in the next analysis in the sweep.
ITLPTRAN	Controls the iteration limit used in the final try of the pseudo-transient method in OP or DC analysis.
ITL1 = x	Maximum DC iteration limit.
ITL2 = x	Iteration limit for the DC transfer curve.
KCLTEST	Starts KCL (Kirchhoff's Current Law) test.
MAXAMP = x	Sets the maximum current, through voltage-defined branches (voltage sources and inductors).
NEWTOL	Calculates one more iterations past convergence for every calculated DC solution and timepoint circuit solution.
NOPIV	
OFF	For all active devices, initializes terminal voltages to zero, if you did not initialize them to other values.

NOPIV	Prevents HSPICE from automatically switching to pivoting matrix factors.
PIVREL = x	Maximum/minimum row/matrix ratio.
PIVTOL = x	Absolute minimum value for which HSPICE or HSPICE RF accepts a matrix entry as a pivot.
RESMIN = x	Minimum resistance for all resistors, including parasitic and inductive resistances.
SPARSE = x	Same as PIVOT.
SYMB = x	If you set the SYMB option to 1, HSPICE operates with a symbolic operating point algorithm to get initial guesses before calculating operating points.

## Pole/Zero Control Options

Option	Description
CSCAL	Sets the capacitance scale. HSPICE multiplies capacitances by CSCAL.
FMAX	Sets the maximum frequency of angular velocity for poles and zeros.
FSCAL	Sets the frequency scale, by which HSPICE or HSPICE RF multiplies the frequency.
GSCAL	Sets the conductance scale.
LSCAL	Sets the inductance scale.
PZABS	Absolute tolerances for poles and zeros.
PZTOL	Relative error tolerance for poles or zeros.
RITOL	Minimum ratio for (real/imaginary) or (imaginary/real) parts of poles or zeros.
(X0R,X0I), (X1R,X1I), (X2R,X2I)	The three complex starting points in the Muller pole/zero analysis algorithm.

See “Pole/Zero Control Options” in the *HSPICE Command Reference*.

## Transient and AC Control Options

Option	Description
ABSH = x	Sets the absolute current change, through voltage-defined branches (voltage sources and inductors).
ABSV = x	Same as VNTOL. See VNTOL.
ACCURATE	Selects a time algorithm; uses LVLTIM=3 and DVDT = 2 for circuits such as high-gain comparators. Default is 0.

<b>Option</b>	<b>Description</b>
ACOUT	AC output calculation method for the difference in values of magnitude, phase, and decibels. Use this option for prints and plots. Default is 1.
CHGTOL = x	Sets a charge error tolerance if you set LVLTIM=2. Default=1e-15 (coulomb).
CSHUNT	Adds capacitance from each node to ground. Default=0.
DI = x	Maximum iteration-to-iteration current change, through voltage-defined branches (voltage sources and inductors). Default is 0.0.
GMIN = x	Minimum conductance added to all PN junctions for a time sweep in transient analysis. Default is 1e-12.
GSHUNT	Adds conductance added from each node to ground. Default=0.
MAXAMP = x	Maximum current, through voltage-defined branches (voltage sources and inductors). If current exceeds the MAXAMP value, HSPICE issues an error. Default=0.0.
RELH = x	Relative current tolerance, through voltage-defined branches (voltage sources and inductors). Default is 0.05.
RELI = x	Relative error/tolerance change, from iteration to iteration. Default is 0.01 for KCLTEST=0 or 1e-6 for KCLTEST=1.
RELQ = x	Used in timestep algorithm for local truncation error (LVLTIM=2). Default=0.01.
RELTOL, RELV	Relative error tolerance for voltages. Default is 1e-3.
RISETIME	Smallest risetime of a signal, <b>.OPTION</b> RISETIME = x.
TRTOL = x	Used in timestep algorithm for local truncation error (LVLTIM=2). Default=7.0.
VNTOL = x, ABSV	Absolute minimum voltage for DC and transient analysis. Default=50 (microvolts).

See “Transient and AC Small Signal Analysis Options” in the *HSPICE Command Reference*.

## Speed Options

AUTOSTOP	Stops transient analysis, after calculating all TRIG-TARG, FIND-WHEN, and FROM-TO measure functions.
BKPSIZ = x	Size of breakpoint table. Default=5000.

BYPASS	To speed-up simulation, does not update status of latent devices. Default is 1.
BYTOL = x	Voltage tolerance, at which a MOSFET, MESFET, JFET, BJT, or diode becomes latent. Default is MBYPASSxVNTOL.
FAST	To speed-up simulation, does not update status of latent devices. Default is 0.
ITLPZ	Sets the iteration limit for pole/zero analysis. Default is 100.
MBYPASS = x	Computes default of BYTOL control option. Default is 1 for DVDT = 0, 1, 2, or 3. Default is 2 for DVDT = 4.
TRCON	Controls automatic convergence, and the speed of large non-linear circuits with large TSTOP/ TSTEP values. Default=1.

## Timestep Options

ABSVAR = x	Absolute limit for the maximum voltage change, from one time point to the next. Default is 0.5 (volts).
DELMAX = x	Maximum Delta of the internal timestep. HSPICE automatically sets the DELMAX value.
DVDT	Adjusts the timestep, based on rates of change for node voltage. Default=4. 0 - original algorithm 1 - fast 2 - accurate 3,4 - balance speed and accuracy
FS = x	Decreases Delta (internal timestep) by the specified fraction of a timestep (TSTEP) for the first time point of a transient. Default=0.25.
FT = x	Decreases Delta (the internal timestep), by a specified fraction of a timestep (TSTEP) for an iteration set that does not converge. Default is 0.25.
IMIN = x, ITL3 = x	Minimum number of iterations. Required to obtain convergence at a timepoint in transient analysis simulations. Determines internal timestep. Default is 3.0.
IMAX = x, ITL4 = x	Maximum number of iterations to obtain convergence at a timepoint in transient analysis. Determines internal timestep. Default is 8.0.

ITL5 = x	Iteration limit for transient analysis output. Default is 0.0.
RELVAR = x	Used with ABSVAR, and DVDT timestep option. Sets relative voltage change for LVLTIM=1 or 3. Default is 0.30 (30%).
RMAX = x	TSTEP multiplier, controls maximum value (DELMAX) to use for internal timestep Delta. Default is 5 when dvdt=4, and lvtim=1. Otherwise, default=2. Maximum is 1e+9, minimum is 1e-9. Recommend maximum=1e+5.
RMIN = x	Sets the minimum value of Delta (internal timestep). Default=1.0e-9.
SLOPETOL = x	Minimum value for breakpoint table entries in a piecewise linear (PWL) analysis. Default is 0.5.
TIMERES = x	Minimum separation between breakpoint values for breakpoint table. Default=1 ps.
WACC = x	Triggers the W element dynamic step control algorithm. x is a real number between 0.0 and 10.0. Larger values result in higher performance and lower accuracy, while smaller values result in lower performance and higher accuracy. If x=0.0, a static step control algorithm is used. Default=0.0.

## Algorithm Options

DVTR	Limits voltage in transient analysis. Default is 1000.
IMAX = x, ITL4 = x	Maximum number of iterations to obtain convergence at a timepoint in transient analysis. Determines internal timestep. Default is 8.0.
IMIN = x, ITL3 = x	Minimum number of iterations. Required to obtain convergence at a timepoint in transient analysis simulations. Determines internal timestep. Default is 3.0.
LVLTIM = x	<p>Selects the timestep algorithm for transient analysis.</p> <p>If LVLTIM = 1 (default), HSPICE uses the DVDT timestep algorithm.</p> <p>If LVLTIM = 2, HSPICE uses the local truncation error (LTE) timestep control method.</p> <p>If LVLTIM = 3, HSPICE uses the DVDT timestep algorithm with timestep reversal.</p>
MAXORD = x	Maximum order of integration for the GEAR method (see METHOD).

METHOD = name	Sets numerical integration method for a transient analysis to GEAR or TRAP.
PURETP	Sets the integration method to use for the reversal time point. Default = 0.
MU = x	Coefficient for trapezoidal integration. Range for MU is 0.0 to 0.5. Default=0.5.
RUNLVL = x	<p>Controls the speed and accuracy trade-off. It can be set to 0,1,2,3,4,5,6. Higher values of RUNLVL result in higher accuracy and longer simulation times, while lower values give lower accuracy and faster simulation runtimes.</p> <p>RUNLVL=0 turns off this algorithm.</p> <p>RUNLVL=1 is the lowest simulation runtime.</p> <p>RUNLVL=3 is the default (similar to original HSPICE default mode).</p> <p>RUNLVL=5, 6 correspond to the HSPICE standard accurate mode. For most circuits, RUNLVL=5 is similar to the HSPICE standard accurate mode.</p>
TRCON	<p>Controls the automatic convergence (autoconvergence) process.</p> <p>TRCON=3: enable auto-speedup only. HSPICE invokes auto-speed up if:</p> <ul style="list-style-type: none"> <li>- there are more than 1000 nodes, or</li> <li>- there are more than 300 active devices, or</li> <li>- Tstop/Tstep (as defined in .TRAN) &gt; 1e8.</li> </ul> <p>When auto-speedup is active, RMAX increases, and HSPICE can take larger timesteps.</p> <p>TRCON=2: enables auto-convergence only. HSPICE invokes auto-convergence if you use the default integration method (trapezoidal), and if HSPICE fails to converge with an "internal timestep too small" error.</p> <p>Auto-convergence sets method=gear, lvtim=2, and starts the transient simulation again from time=0.</p> <p>TRCON=1: enables both auto-convergence and auto-speedup.</p> <p>TRCON=0: disables both auto-convergence and auto-speedup (default).</p> <p>TRCON=-1: same as TRCON=0.</p>

## Input and Output Options

INTERP	Limits output for post-analysis tools, such as Cadence or Zuken to only .TRAN timestep intervals.
ITRPR	Prints output variables, at their internal timepoints.
MCBRIEF = x	Controls how HSPICE outputs Monte Carlo parameters.
MEASFAIL	If MEASFAIL=0, outputs 0 into the .mt#, .ms#, or .ma# file, and prints failed to the listing file. If MEASFAIL=1 (default), prints failed into the .mt#, .ms#, or .ma# file, and into the listing file.
MEASFILE = x	If MEASFILE=0, outputs measure information to several files. If MEASFILE=1 (default), outputs measure information to a single file.
MEASSORT	This option is no longer necessary and is ignored.
PUTMEAS	Controls the output variables, listed in the .MEASURE statement. Default = 1.
UNWRAP	Displays phase results from AC analysis in unwrapped form (continuous phase plot).

## AC Control Options

ABSH=x	Sets the absolute current change, through voltage-defined branches (voltage sources and inductors).
ACOUT	AC output calculation method for the difference in values of magnitude, phase, and decibels for prints and plots.
DI=x	Sets the maximum iteration-to-iteration current change, through voltage-defined branches (voltage sources and inductors).
MAXAMP = x	Sets the maximum current, through voltage-defined branches (voltage sources and inductors).
RELH = x	Relative current tolerance, through voltage-defined branches (voltage sources and inductors).
UNWRAP	Displays phase results from AC analysis in unwrapped form (continuous phase plot).

## Common Model Interface Options

CMIFLAG	Controls loading of the CMI library.
CUSTCMI=x	Controls gate tunneling current modeling and additional instance parameter support for Customer CMI with topoid=0.



## Verilog-A Options

SPMODEL	In this option, the name is the cell name that uses a SPICE definition.
VAMODEL	This option specifies that the <i>name</i> is the cell name that uses a Verilog-A definition rather than the subcircuit definition when both exist.

---

## Statements

HSPICE supports the following statements:

### .ALTER Statement

---

General Form	<b>.ALTER</b> <title_string>
--------------	------------------------------

---

See “**.ALTER**” in the *HSPICE Command Reference*.

### Comments

---

General Form	*<Comment on a line by itself>
Or	<HSPICE statement> \$<comment following HSPICE input>

---

### .ALIAS Statement

You can alias one model name to another:

```
.alias pa1 par1
```

During simulation, this **.ALIAS** statement indicates to use the par1 model in place of a reference to a previously-deleted pa1 model. See “**.ALIAS**” in the *HSPICE Command Reference*.

## **.CONNECT Statement**

Connects two nodes in your HSPICE netlist so that simulation evaluates the two nodes as only one node. Both nodes must be at the same level in the circuit design that you are simulating; you cannot connect nodes that belong to different subcircuits. You also cannot use this statement in HSPICE RF.

**.CONNECT** node1 node2

where:

- node1     Name of the first of two nodes to connect to each other.
- node2     Name of the second of two nodes to connect to each other. The first node replaces this node in the simulation.

## **.DATA Statement**

See “.DATA” in the *HSPICE Command Reference*.

### **Inline .DATA Statement**

---

General Form     **.DATA** datanm pnam1 <pnam2  
                         + pnam3 ...pnamxxx >  
                         + pval1<pval2 pval3 ...  
                         + pvalxxx> pval1' <pval2'  
                         + pval3' ...pvalxxx'>  
                         **.ENDDATA**

---

### **External File .DATA Statement**

---

General Form     **.DATA** datanm  
                         + MER FILE = 'filename1'  
                         + pname1=colnum  
                         + <pname2=colnum ...>  
                         + <FILE = 'filename2'  
                         + pname1 = colnum  
                         + <pname2 = colnum ...>> ...  
                         + <OUT = 'fileout'>  
                         **.ENDDATA**

---

## Column Laminated .DATA Statement

---

General Form    **.DATA** *datanm*  
                  + LAM FILE='filename1'  
                  + *pname1=colnum*  
                  + <*pname2=colnum ...*>  
                  + <FILE='filename2'  
                  + *pname1=colnum*  
                  + <*pname2=colnum ...*>...  
                  + <OUT = 'fileout'  
                  **.ENDDATA**

---

datanm	Specifies the data name referred to in the <b>.TRAN</b> , <b>.DC</b> , or <b>.AC</b> statement.
LAM	Specifies column-laminated (parallel merging) data files to use.
filenameei	Specifies the name of the data file to read.
MER	Specifies concatenated (series merging) data files to use.
pnamei	Specifies the parameter names used for source value, element value, device size, model parameter value, and so on.
colnum	Specifies the column number in the data file for the parameter value.
fileout	Specifies the name of the data file to write with all of the data concatenated.
pvali	Specifies the parameter value.

See “Column Laminated .DATA Statement” in the *HSPICE Simulation and Analysis User Guide*.

## .DEL LIB Statement

---

General Form    **.DEL LIB** '<filepath>filename'  
                  + *entryname*  
                  **.DEL LIB** *libnumber entryname*

---

entryname	Entry name, used in the library call statement to delete.
filename	Name of a file to delete from the data file.
filepath	Path name of a file, if the operating system supports tree-structured directories.
libnumber	Library number, used in the library call statement to delete.

See “**.DEL LIB**” in the *HSPICE Command Reference*.

## Element Statements

---

General Form	eIname <node1 node2 ... nodeN> + <mname> <pname1 = val1> + <pname2 = val2> <M = val>
Or	eIname <node1 node2 ... nodeN> + <mname> <pname = 'expression'> + <M = val>
Or	eIname <node1 node2 ... nodeN> + <mname> <val1 val2 ... valn>

---

B	IBIS buffer
C	Capacitor
D	Diode
E,F,G,H	Dependent current and voltage sources
I	Current source
J	JFET or MESFET
K	Mutual inductor
L	Inductor
M	MOSFET
Q	BJT
R	Resistor
S	S element
T,U,W	Transmission line
V	Voltage source
X	Subcircuit call

expression	Any mathematical expression containing values or parameters, i.e., param1 * val2.
eIname	Element name that cannot exceed 1023 characters, and must begin with a specific letter for each element type.
M = val	Element multiplier.
mname	Model reference name is required for all elements except passive devices.
node1 ...	Node names are identifiers of the nodes to which the element is connected.
pname1 ...	Element parameter name used to identify the parameter value that follows this name.
val1...	Value assigned to the parameter pname1 or to the corresponding model node.

See “Element and Source Statements” in the *HSPICE Simulation and Analysis User Guide*.

## **.END Statement**

---

General Form	<b>.END</b> <comment>
comment	Any comment, normally the name of the data file being terminated.

---

See “.END” in the *HSPICE Command Reference*.

## **.GLOBAL Statement**

---

General Form	<b>.GLOBAL</b> node1 node2 node3 ...
--------------	--------------------------------------

---

See “.GLOBAL” in the *HSPICE Command Reference*.

## **.IC/.DCVOLT Initial Condition Statement**

---

General Form	<b>.IC</b> $v(\text{node1})=\text{val } 1$ $v(\text{node2})=$ $+ \text{val } 2 \dots$
Or	<b>.DCVOLT</b> $V(\text{node1})=\text{val } 1$ $+ V(\text{node2})=\text{val } 2$

---

See “.IC” and “.DCVOLT” in the *HSPICE Command Reference*.

## **.IF-.ELSEIF-.ELSE-.ENDIF Statements**

You can use this *if-else* structure to change the circuit topology, expand the circuit, set parameter values for each device instance, or select different model cards in each *if-else* block.

```
.IF (condition1)  
...  
< .ELSEIF (condition2)  
... >  
< .ELSE  
... >  
.ENDIF
```

## **.INCLUDE Statement**

---

General Form	<b>.INCLUDE</b> '<filepath> filename'
--------------	---------------------------------------

---

## **.LIB Library Call Statement**

---

General Form	<b>.LIB</b> '<filepath> filename' entryname
entryname	Entry name for the section of the library file to include.

---

filename	Name of a file to include in the data file.
filepath	Path to a file.

## .LIN Statement

---

General Form	<b>.LIN</b> <sparcalc = [1 0] <modelname = ...>> + <filename = ...> <format=[selem citi touchstone]> + <noisecalc = [1 0] <gdcalc = [1 0]> + <mixedmode2port = [dd dc ds cd cc cs sd sc ss]>
--------------	---

---

sparcalc	If 1, extract S parameters (default).
modelname	Model name listed in the <b>.MODEL</b> statement in the .sc# model output file.
filename	Output file name (default=netlist name).
format	Output file format: - selem is for S element .sc# format, which you can include in the netlist. - citi is CITIfile format. - touchstone is TOUCHSTONE file format.
noisecalc	If 1, extract noise parameters (perform 2-port noise analysis). Default=0.
gdcalc	If 1, extract group delay (perform group delay analysis). Default=0.
mixedmode2port	The mixedmode2port keyword describes the mixed-mode data map of output mixed mode S parameter matrix. The availability and default value for this keyword depends on the first two port (P element) configuration as follows: case 1: p1=p2=single (standard mode P element) available: ss default: ss case 2: p1=p2=balanced (mixed mode P element) available: dd, cd, dc, cc default: dd case 3: p1=balanced p2=single available: ds, cs default: ds case 4: p1=single p2=balanced available: sd, sc default: sd

## **.LIB Library File Definition Statement**

---

General Form    **.LIB** entryname1  
                  .  
                  .\$ ANY VALID SET OF HSPICE  
                  + STATEMENTS  
                  .  
                  **.ENDL** entryname1  
                  **.LIB** entryname2  
                  .  
                  .\$ ANY VALID SET OF HSPICE  
                  + STATEMENTS  
                  .  
                  **.ENDL** entryname2  
                  **.LIB** entryname3  
                  .  
                  .\$ ANY VALID SET OF HSPICE  
                  + STATEMENTS  
                  .  
                  **.ENDL** entryname3

---

The text following a library file entry name must consist of valid HSPICE statements. See “.LIB Library File Definition Statement” in the *HSPICE Simulation and Analysis User Guide*.

## **.LIB Nested Library Calls**

Library calls may be nested in other libraries provided they call different files. Library calls may be nested to any depth. See “.LIB Nested Library Calls” in the *HSPICE Simulation and Analysis User Guide*.

## **.MALIAS Statement**

You can use the **.MALIAS** statement to assign an alias (another name) to a diode, BJT, JFET, or MOSFET model that you defined in a **.MODEL** statement. You can also use the **.MALIAS** statement to assign an alias to a subcircuit defined in a **.SUBCKT** statement. See **.MALIAS** Statement in the *HSPICE Command Reference*.

You cannot use the **.MALIAS** statement in HSPICE RF. The syntax of the **.MALIAS** statement is:

**.MALIAS** model\_name=alias\_name1 <alias\_name2 . . .>

## **.MODEL Statement**

---

General Form **.MODEL** mname type  
+ <VERSION = version\_number>  
+ <pname1 = val1 pname2 = val2 ...>

---

VERSION HSPICE version number, used to allow portability of the BSIM (LEVEL=13), BSIM2 (LEVEL = 39) models between HSPICE releases. Version parameter also valid for LEVEL 49, 53, 54, 57, and 59.

mname Model name reference.

pname1 ... Parameter name.

type Selects the model type, which must be one of the following:

For HSPICE:

AMP operational amplifier model

C capacitor model

COREmagnetic core model

D diode model

L magnetic core mutual inductor

NJF n-channel JFET model

NMOSn-channel MOSFET model

NPN npn BJT model

OPT optimization model

PJF p-channel JFET model

PLOTplot model for .GRAPH statement

PMOSp-channel MOSFET model

PNP pnp BJT model

R resistor model

U lossy transmission line (lumped)

W lossy transmission line model

S S model

SP Frequency table model

For HSPICE RF:

C capacitor model

D diode model

R resistor model

W lossy transmission line model

See “**.MODEL**” in the *HSPICE Command Reference*.

## **.NODESET Statement**

---

General **.NODESET** V(node1) = val1  
Form + <V(node2) = val2 ...>

Or **.NODESET** node1 val1 <node2 val2>

---

node1... Node numbers or node names can include full path names or circuit numbers



val1                    Specifies voltage.

See “.NODESET” in the *HSPICE Command Reference*.

## **.PARAM Statement**

---

General                **.PARAM** <ParamName>=<RealNumber>  
Form

See “.PARAM” in the *HSPICE Command Reference*.

## **Algebraic Format**

---

General Form        **.PARAM** <ParamName>=<AlgebraicExpression>  
                         **.PARAM**<ParamName1>=<ParamName2>

Quotes around the algebraic expression are mandatory.  
See “Algebraic Parameter (Equation)” in the *HSPICE Simulation and Analysis User Guide*.

## **Optimization Format**

---

General Form        OPTIMIZE=opt\_pav\_fun

Or (element        **.PARAM** <ParamName>=<OptParamFunc> (<Init>,  
or model            <LoLim>, <Hi Lim>, <Inc>)  
keyname)

---

paramname1        Parameter names are assigned to values

...

OptParmFunc       Optimization parameter function (string)

Init                Initial value of parameter (real)

LoLim              Lower limit for parameter (real)

HiLim              Upper limit for parameter (real)

Inc                 Rounds to nearest <Inc> value (real)

A parameter can be used in an expression only if it is defined.

## **.PROTECT Statement**

---

General                **.PROTECT**  
Form

---

The **.PROTECT** command suppresses the print back of text. See “.PROTECT” in the *HSPICE Command Reference*.

## **.TITLE Statement**

---

General Form	Any string of up to 72 characters
--------------	-----------------------------------

Or	<b>.TITLE</b> "any string"
----	----------------------------

---

Title	The first line of the simulation is always the title.
-------	---

See **".TITLE"** in the *HSPICE Command Reference*.

## **.UNPROTECT Statement**

---

General Form	<b>.UNPROTECT</b>
--------------	-------------------

---

The **.UNPROTECT** command restores normal output functions from a **.PROTECT** command. See **".UNPROTECT"** in the *HSPICE Command Reference*.

## **.WIDTH Statement**

---

General Form	<b>.WIDTH</b> OUT={80 132}
--------------	----------------------------

---

OUT	The output print width. Permissible values are 80 and 132.
-----	--

See **".WIDTH"** in the *HSPICE Command Reference*.

---

# **Analyzing Data**

You can perform several types of analyses with HSPICE.

---

## **DC Analysis**

HSPICE can perform the following types of DC analyses.

### **.DC Statement—DC Sweep**

See **".DC"** in the *HSPICE Command Reference*.

### **Sweep or Parameterized Sweep**

---

General Form	<b>.DC</b> var1 start1 stop1 incr1 + <SWEEP var2 type np + start2 stop2>
--------------	--

Or	<b>.DC</b> var1 start1 stop1 incr1 + <var2 start2 stop2 incr2>
----	---

---

## Data-Driven Sweep

---

General Form	<b>.DC</b> <i>var1 type np start1 stop1</i> + <SWEEP DATA = <i>datanm</i> >
Or	<b>.DC</b> DATA = <i>datanm</i> + <SWEEP <i>var2 start2 stop2</i> + <i>incr2</i> >
Or	<b>.DC</b> DATA = <i>datanm</i>

---

## Monte Carlo

---

General Form	<b>.DC</b> <i>var1 type np start1 stop1</i> + <SWEEP MONTE = <i>val</i> > < <i>firstrun</i> = <i>num1</i> >
Or	<b>.DC</b> <i>var1 type np start1 stop1</i> + <SWEEP MONTE = list<(> < <i>num1:num2</i> > + < <i>num3</i> > < <i>num5:num6</i> > < <i>num7</i> > <)> >
Or	<b>.DC</b> MONTE = <i>val</i> < <i>firstrun</i> = <i>num1</i> >
Or	<b>.DC</b> MONTE = list<(> < <i>num1:num2</i> > + < <i>num3</i> > < <i>num5:num6</i> > < <i>num7</i> > <)>

---

## Optimization

---

General Form	<b>.DC</b> DATA = <i>datanm</i> OPTIMIZE = + <i>opt_par_fun</i> RESULTS = + <i>measnames</i> MODEL = <i>optmod</i>
Or	<b>.DC</b> <i>var1 start1 stop1 SWEEP</i> + OPTIMIZE = OPT <i>xxx</i> + RESULTS = <i>measname</i> + MODEL = <i>optmod</i>

---

DC analysis statement     **.DC** <DATA=*filename*> SWEEP  
+ OPTIMIZE=OPT*xxx*  
+ RESULTS=*ierr1* ... *ierrn*  
+ MODEL=*optmod*

---

DATA=*datanm*     *Datanm* is the reference name of a **.DATA** statement.

*incr1* ...     Voltage, current, element, model parameters, or temperature increment values.

MODEL     Optimization reference name, used in the **.MODEL** OPT statement.

MONTE=*val*     Produces a number (*val*) of randomly generated values, which select parameters from a distribution.

*np*     Number of points per decade (or depending on the preceding keyword).

OPTIMIZE     Specifies the parameter reference name used in the **.PARAM** statement.

---

RESULTS	Specifies the measure name used in the <b>.MEASURE</b> statement.
start1 ...	Starting voltage, current, element, model parameters, or temperature values.
stop1 ...	Final voltage, current, any element, model parameter, or temperature values.
SWEEP	Indicates that a second sweep has a different variation type (DEC, OCT, LIN, POI, DATA statement, or MONTE = <i>val</i> ).
TEMP	Indicates a temperature sweep.
type	Can be any of the following keywords: DEC, OCT, LIN, POI.
var1 ...	Name of an independent voltage or current source, any element or model parameter, or the TEMP keyword.

## **.DCMATCH Statement—DC Mismatch**

See “**.DCMATCH**” in the *HSPICE Command Reference*.

---

General Form	<b>.DCMATCH</b> OUTVAR <THRESHOLD= <i>T</i> > + <FILE= <i>string</i> > <PERTURBATION= <i>P</i> > + <INTERVAL= <i>Int</i> >
--------------	--

---

OUTVAR	Valid node voltages, the difference between node pairs or branch currents.
Threshold	Report devices with a relative contribution above Threshold in the summary table. <i>T</i> =0: reports results for all devices <i>T</i> <0: suppresses table output; however, individual results are still available through <b>.PROBE</b> or <b>.MEASURE</b> statements. The upper limit for <i>T</i> is 1, but at least 10 devices are reported, or all if there are less than 10. Default value is 0.01.
File	Valid file name for the output tables. Default is <i>basename.d#</i> where “#” is the usual sequence number for HSPICE output files.
Perturbation	Indicates that perturbations of <i>P</i> standard deviation will be used in calculating the finite difference approximations to device derivatives. The valid range for <i>P</i> is 0.01 to 6, with a default value of 2.

Interval Applies only if a DC sweep is specified. *Int* is a positive integer. A summary is printed at the first sweep point, then for each subsequent increment of *Int*, and then, if not already printed, at the final sweep point. Only single sweeps are supported.

See “.DCMATCH” in the *HSPICE Command Reference*.

## DCmatch Definition Block

---

```
.Variation
.Local_Variation
modelType modelName modelParam1='Expression1 for Sigma'
+ modelParam2='Expression2 for Sigma'
.End_Local_Variation
.End_Variation
```

---

modelType	Identifies a model type.
modelName	Model name reference.
modelParam1,2	Defines DCmatch variation for a model parameter of the device specified. The expression can be a constant, parameter, or a function containing allowed instance parameters. Add a space and % character after the expression to specify the variation as a percentage of the nominal value.

---

## .OP Statement—Operating Point

---

General Form	<b>.OP</b> <format> <time> <format> <time> ... <interpolation>
format	Any of the following keywords: ALL, BRIEF, CURRENT, DEBUG, NONE, VOLTAGE.
time	Parameter after ALL, VOLTAGE, CURRENT, or DEBUG to specify the time at which the report is printed.
interpolation	Selects an interpolation method for <b>.OP</b> time points to display during transient analysis.

See “.OP” in the *HSPICE Command Reference*.

## **.PZ Statement—Pole/Zero Analysis**

---

General Form	<b>.PZ</b> ov srcnam
ov	Output variable: a node voltage $V(n)$ or branch current $I(element)$
srcnam	Input source: an independent voltage or current source name

---

See “.PZ” in the *HSPICE Command Reference*.

## **.SENS Statement—DC Sensitivity Analysis**

---

General Form	<b>.SENS</b> ov1 <ov2 ...>
ov1 ov2 ...	Branch currents or nodal voltage for DC component sensitivity analysis.

---

See “.SENS” in the *HSPICE Command Reference*.

## **.TF Statement—DC Small-Signal Transfer Function Analysis**

---

General Form	<b>.TF</b> ov srcnam
ov	Small-signal output variable
srcnam	Small-signal input source

---

See “.TF” in the *HSPICE Command Reference*.

---

## **AC Analysis**

### **.AC Statement**

#### **Single/Double Sweep**

---

General Form	<b>.AC</b> type np fstart fstop
Or	<b>.AC</b> type np fstart fstop + <SWEEP var <START=>start + <STOP=>stop <STEP=>incr>
Or	<b>.AC</b> type np fstart fstop <SWEEP var type np start stop>

---

Or `.AC type np fstart fstop`  
`+ <SWEEP var`  
`+ START="param_expr1"`  
`+ STOP="param_expr2"`  
`+ STEP="param_expr3">`

Or `.AC type np fstart fstop`  
`+ <SWEEP var start_expr`  
`+ stop_expr step_expr>`

See **“.AC”** in the *HSPICE Command Reference*.

## Parameterized Sweep

---

General Form `.AC type np fstart fstop <SWEEP`  
`DATA = datanm>`

Or `.AC DATA = datanm`

Or `.AC DATA = datanm <SWEEP var`  
`+ <START=>start <STOP=>stop`  
`+ <STEP=>incr>`

Or `.AC DATA = datanm <SWEEP var`  
`+ type np start stop>`

Or `.AC DATA = datanm <SWEEP var`  
`+ START="param_expr1"`  
`+ STOP="param_expr2"`  
`+ STEP="param_expr3">`

Or `.AC DATA = datanm <SWEEP var`  
`+ start_expr stop_expr`  
`+ step_expr>`

## Optimization

---

General Form `.AC DATA = datanm`  
`+ OPTIMIZE = opt_par_fun`  
`+ RESULTS = measnames`  
`+ MODEL = optmod`

AC analysis statement `.AC <DATA=filename> SWEEP`  
`+ OPTIMIZE=OPTxxx`  
`+ RESULTS=ierr1 ... ierrn`  
`+ MODEL=optmod`

---

## Random/Monte Carlo

---

General Form `.AC type np fstart fstop`  
`+ <SWEEP MONTE = val> <firstrun = num1>`  
`or`  
`.AC type np fstart fstop`  
`+ <SWEEP MONTE = list(< <num1:num2>`  
`+ <num3> <num5:num6> <num7> <)> >`

---

DATA= <i>datanm</i>	Data name referenced in the <b>.AC</b> statement.
fstart	Starting frequency. If you use POI (list of points) type variation, use a list of frequency values, not fstart fstop.
fstop	Final frequency.
incr	Increment value of the voltage, current, element, or model parameter. If you use <i>type</i> variation, specify the np (number of points) instead of incr.
MONTE = <i>val</i>	Produces a number ( <i>val</i> ) of randomly-generated values (HSPICE only; not supported in HSPICE RF). HSPICE uses these values to select parameters from a distribution, either Gaussian, Uniform, or Random Limit.
np	Number of points, points per decade, or octave, depending on which keyword precedes it.
start	Starting voltage, current, or any parameter value for an element or a model.
stop	Final voltage, current, or any parameter value for an element or a model.
SWEEP	This keyword indicates that the <b>.AC</b> statement specifies a second sweep.
TEMP	This keyword indicates a temperature sweep
firstrun	The <i>val</i> value specifies the number of Monte Carlo iterations to perform. The firstrun value specifies the desired number of iterations. HSPICE runs from num1 to num1+ <i>val</i> -1.
list	The iterations at which HSPICE performs a Monte Carlo analysis. You can write more than one number after <i>list</i> . The colon represents "from ... to ...". Specifying only one number makes HSPICE run at only the specified point.
type	Can be any of the following keywords: DEC – decade variation. OCT – octave variation. LIN – linear variation. POI – list of points.
var	Name of an independent voltage or current source, element or model parameter, or the TEMP (temperature sweep) keyword.



## .DISTO Statement—AC Small-Signal Distortion Analysis

---

General Form	<b>.DISTO</b> Rload <inter <skw2 + <refpwr <spwf>>>>
inter	Interval at which HSPICE prints a distortion-measure summary.
refpwr	Reference power level, used to compute the distortion products.
Rload	Element name of the output load resistor, into which the output power feeds.
skw2	Ratio of the second frequency (F2) to the nominal analysis frequency (F1).
spwf	Amplitude of the second frequency (F2).

---

See “.DISTO” in the *HSPICE Command Reference*.

## .LIN Statement—AC Linear Parameter Extraction Analysis

---

General Form	<b>.LIN</b> sparcalc=1 + modelname= <i>my_custom_model</i> + filename= <i>mydesign</i> format= <i>touchstone</i> + noisecalc=1 gdcalc=1 + dataformat=[ri   ma   db]
sparcalc	Flag to do S parameter extraction. Default=1
modelname	The model name to store the S Parameters.
filename	The name of output data file.
format	Data file format: TOUCHSTONE, CITIfile, or .sc* file.
noisecalc	Flag to do two-port noise analysis. Default=0.
gdcalc	Flag to do group delay analysis. Default=0.
dataformat	Data format in the output data file: RI/MA/DB

---

See “.LIN” in the *HSPICE Command Reference*.

## .NOISE Statement—AC Noise Analysis

---

General Form	<b>.NOISE</b> ovr srcnam inter
inter	Interval at which HSPICE or HSPICE RF prints a noise analysis summary; inter specifies how many frequency points to summarize in the AC sweep.
ovv	Nodal voltage output variable, defining the node at which HSPICE or HSPICE RF sums the noise.
srcnam	Name of the independent voltage or current source to use as the noise input reference.

---

See “.NOISE” in the *HSPICE Command Reference*.

## .SAMPLE Statement—Noise Folding Analysis

---

General Form	<b>.SAMPLE</b> FS = freq <TOL = val> + <NUMF = val> <MAXFLD = val> + <BETA = val>
BETA	Integrator duty cycle; specifies an optional noise integrator at the sampling node.
FS = freq	Sample frequency in hertz.
MAXFLD	Maximum number of folding intervals.
NUMF	Maximum allowed number of frequencies that you can specify.
TOL	Sampling error tolerance.

---

See “.SAMPLE” in the *HSPICE Command Reference*.

---

## Small-Signal Network Analysis

### .NET Statement—AC Network Analysis

#### One-port network

---

General Form	<b>.NET</b> input <RIN = val>
Or	<b>.NET</b> input <val>

---

#### Two-port network

---

General Form	<b>.NET</b> output input + <ROUT = val> <RIN = val>
input	Name of the voltage or current source for AC input.

---

output	Output port. It can be: An output voltage, V(n1,n2). An output current, I(source), or I(element).
RIN	Keyword for input or source resistance. The RIN value calculates output impedance, output admittance, and scattering parameters. The default RIN value is 1 ohm.
ROUT	Keyword for output or load resistance. The ROUT value calculates input impedance, admittance, and scattering parameters. The default ROUT value is 1 ohm.

See “.NET” in the *HSPICE Command Reference*.

## AC Network Analysis—Output Specification

General Form	Xij(z), ZIN(z), ZOUT(z), YIN(z), YOUT(z)
ij	Identifies which matrix parameter to print.
X	Specifies Z for impedance, Y for admittance, H for hybrid, or S for scattering.
YIN	Input admittance.
YOUT	Output admittance.
z	Output type: R, I, M, P, DB, T.
ZIN	Input impedance.
ZOUT	Output impedance.

See “AC Network Analysis - Output Specification” in the *HSPICE Simulation and Analysis User Guide*.

## Temperature Analysis

### .TEMP Statement

General Form	.TEMP t1 <t2 <t3 ...>>
t1 t2 ...	Temperatures in °C, at which HSPICE or HSPICE RF simulates the circuit.

See “.TEMP” in the *HSPICE Command Reference*.

---

## Transient Analysis

### .TRAN Statement

See “**.TRAN**” in the *HSPICE Command Reference*.

### Single-Point Analysis

```
.TRAN tincr1 tstop1 <tincr2 tstop2 ...tincrN tstopN>  
+ <START = val> <UIC>
```

### Double-Point Analysis

```
.TRAN tincr1 tstop1 <tincr2  
tstop2 ...tincrN tstopN>  
+ <START = val> <UIC>  
+ <SWEEP var type np pstart pstop>  
or
```

```
.TRAN tincr1 tstop1 <tincr2  
tstop2 ...tincrN tstopN>  
+ <START = val> <UIC> <SWEEP var  
+ START="param_expr1" STOP="param_expr2"  
+ STEP="param_expr3">  
or
```

```
.TRAN tincr1 tstop1 <tincr2 tstop2 ...  
tincrN tstopN>  
+ <START=val> <UIC> <SWEEP var start_expr  
+ stop_expr step_expr>
```

### Data-Driven Sweep

---

General Form      **.TRAN** DATA = datanm  
(data-driven  
sweep)

---

Or                    **.TRAN** tincr1 tstop1 <tincr2 tstop2...tincrN  
+ tstopN> <START = val> <UIC>  
+ <SWEEP DATA = datanm>

Or                    **.TRAN** DATA = datanm <SWEEP var  
+ <START=>pstart <STOP=>pstop  
+ <STEP=>pincr>

Or                    **.TRAN** DATA = datanm <SWEEP var  
+ type np pstart pstop>

Or `.TRAN DATA = datanm <SWEEP var  
+ START="param_expr1"  
+ STOP="param_expr2"  
+ STEP="param_expr3">`

Or `.TRAN DATA = datanm <SWEEP var  
+ start_expr stop_expr step_expr>`

## Monte Carlo Analysis

---

General Form `.TRAN tincr1 tstop1 <tincr2 tstop2  
+ ...tincrN tstopN> <START = val>  
+ <UIC><SWEEP MONTE = val>  
+ <firstrun = num1>`

Or `.TRAN tincr1 tstop1 <tincr2 tstop2  
+ ...tincrN tstopN> <START = val>  
+ <UIC><SWEEP MONTE = list<(>  
+ <num1:num2> <num3>  
+ <num5:num6> <num7> <)> >`

---

## Optimization

---

General Form `.TRAN DATA = datanm OPTIMIZE =  
+ opt_par_fun RESULTS = measnames  
+ MODEL = optmod`

TRAN analysis statement `.TRAN <DATA=filename> SWEEP  
+ OPTIMIZE=OPTxxx  
+ RESULTS=ierr1 ... ierrn  
+ MODEL=optmod`

---

DATA = datanm Data name referenced in the .TRAN statement.

MONTE = val Produces a number *val* of randomly-generated values used to select parameters from a distribution.

np Number of points per decade (or depending on the preceding keyword).

param\_expr... User-specified expressions.

pincr Voltage, current, element, or model parameter, or temperature increment value.

pstart Starting voltage, current, temperature, any element, or model parameter value.

pstop Final voltage, current, temperature, any element, or model parameter value.

START Time at which printing/plotting begins.

SWEEP Indicates a second sweep is specified on the .TRAN statement.

tincr1...	Printing/plotting increment for printer output, and the suggested computing increment for the postprocessor.
tstop1...	Time at which the transient analysis stops incrementing by tincr1.
type	Specifies any of the following keywords: DEC, OCT, LIN, POI.
UIC	Causes HSPICE to use the nodal voltages specified in the <b>.IC</b> statement (or by the "IC = " parameters in the various element statements) to calculate the initial transient conditions, rather than solving for the quiescent operating point.
var	Name of an independent voltage or current source, any element or model parameter, or the keyword TEMP.

## **.BIASCHK Statement**

---

General Form	<p>As an expression monitor:</p> <pre><b>.BIASCHK</b> 'expression' &lt;limit = <i>lim</i>&gt; &lt;noise = <i>ns</i>&gt; + &lt;max = <i>max</i>&gt; &lt;min = <i>min</i>&gt; + &lt;simulation = op   dc   tr   all&gt; &lt;monitor = v   i   w   l &gt; + &lt;tstart = <i>time1</i>&gt; &lt;tstop = <i>time2</i>&gt; &lt;autostop&gt;</pre> <p>As an element and model monitor:</p> <pre><b>.BIASCHK</b> <i>type</i> &lt;region=cutoff   linear   saturation&gt; + terminal1=<i>t1</i> &lt;terminal2=<i>t2</i>&gt; &lt;limit=<i>lim</i>&gt; + &lt;noise=<i>ns</i>&gt; &lt;max=<i>max</i>&gt; &lt;min=<i>min</i>&gt; + &lt;simulation=op   dc   tr   all&gt; &lt;monitor=v   i   w   l&gt; + &lt;name=<i>name1</i>, <i>name2</i>, ...&gt; + &lt;mname=<i>modname_1</i>, <i>modname_2</i>, ...&gt; + &lt;tstart=<i>time1</i>&gt; &lt;tstop=<i>time2</i>&gt; &lt;autostop&gt; + &lt;except=<i>name_1</i>,<i>name_2</i>, ...&gt;</pre>
type	Element type to check.
terminal 1, terminal2	Terminals, between which HSPICE checks (checks between terminal1 and terminal2)
limit	Biaschk limit that you define.
noise	Biaschk noise that you define. The default is 0.1v.
max	Maximum value.
min	Minimum value.
name	Element or instance name to check.
mname	Model or subcircuit name. For model name, HSPICE checks elements for bias. For subcircuit name, HSPICE checks instances for bias.

region	Values can be cutoff, linear, or saturation. HSPICE monitors when the MOS device, defined in the <b>.BIASCHK</b> command, enters and leaves the specified region (such as cutoff).
simulation	The simulation type you want to monitor. You can specify op, dc, tr (transient), and all (op, dc, and tr). The tr option is the default simulation type.
monitor	The kind of value you want to monitor. You can specify v (voltage), i (current), w, and l (device size) for the element type. This parameter is not used for an expression-type monitor.
tstart	The biaschk start time during transient analysis. The default is 0.
tstop	The biaschk end time during transient analysis. The analysis ends on its own by default if you do not set this parameter.
autostop	If you set this keyword HSPICE supports autostop for this biaschk card so that it can report error message and stop the simulation immediately.
except	Specifies the element or instance that this instatement does not need to check. This parameter is not used for an expression type monitor.

You can use a wild card to describe *name*, *mname*, or “except” parameter in the biaschk card.

- ? stands for one character
- \* stands for 0 or more characters.

If *type* is “subckt”, then a bias check is done for subcircuit instances. In which case, the rules are:

- After one and only one *mname* has been defined, the terminal names for this statement are those pins defined by the subckt definition of *mname*.
- Multiple *mname* parameters are not allowed if bias checking for subcircuit pins; therefore, wild carding is not supported for *mname* for bia checking of subcircuits.
- When both *mname* and *name* are defined while multiple *name* are allowed, and if any specified *name* is also an instance of *mname*, then only those *name* definitions will be checked and the others will be ignored. If none of the *name* definitions are instances of *mname*, then this statement will be ignored.

- If *mname* has not been defined, then the subcircuit type is determined by the first specification of *name*.
- For a subcircuit bias check, at least one *name* or *mname* must be specified in this statement.

## Options for the .BIASCHK Command

Output file defined option:

---

General Form      **.OPTION** biasfile=biaschk/mos.bias

---

Warning message turn off (on) option:

---

General Form (on)                      **.OPTION** biawarn=1

---

General Form (off, default)      **.OPTION** biawarn=0

## Numerical Integration Algorithm Controls

See “Numerical Integration Algorithm Controls (HSPICE)” in the *HSPICE Simulation and Analysis User Guide*.

### Gear Algorithm

---

General Form      **.OPTION** METHOD=GEAR

---

### Backward-Euler

---

General Form      **.OPTION** METHOD=GEAR MU = 0

---

### Trapezoidal Algorithm

---

General Form      **.OPTION** METHOD=TRAP

---



---

## FFT Analysis

### .FFT Statement

---

General Form      **.FFT** *output\_var* <START = *value*>  
                          + <STOP = *value*> <NP = *value*>  
                          + <FORMAT = *keyword*>  
                          + <WINDOW = *keyword*>  
                          + <ALFA = *value*> <FREQ = *value*>  
                          + <FMIN = *value*> <FMAX = *value*>

---



ALFA	Parameter used in GAUSS and KAISER windows to control the highest side-lobe LEVEL, bandwidth, and so on.
FMAX	Maximum frequency for which HSPICE prints FFT output into the listing file. THD calculations also use this frequency.
FMIN	Minimum frequency for which HSPICE prints FFT output into the listing file. THD calculations also use this frequency.
FORMAT	Output format. NORM= normalized magnitude UNORM=unnormalized magnitude
FREQ	Frequency to analyze.
FROM	An alias for START.
NP	Number of points to use in FFT analysis.
output_var	Any valid output variable, such as voltage, current, or power.
START	Beginning of the output variable waveform to analyze.
STOP	End of the output variable waveform to analyze.
TO	An alias for STOP.
WINDOW	Window type to use: RECT, BART, HANN, HAMM, BLACK, HARRIS, GAUSS, KAISER.

See “.FFT” in the *HSPICE Command Reference*.

---

## Worst Case Analysis

See “Worst Case Analysis” in the *Simulation and Analysis User Guide*.

## Sigma Deviations

Type	Param	Slow	Fast
NMOS	XL	+	-
	RSH	+	-
	DELVTO	+	-
	TOX	+	-
	XW	-	+

Type	Param	Slow	Fast
PMOS	XL	+	-
	RSH	+	-
	DELVTO	-	+
	TOX	+	-
	XW	-	+

## Monte Carlo Analysis

HSPICE statements needed to set up a Monte Carlo analysis are:

- **.PARAM** statement.
- **.DC**, **.AC**, or **.TRAN** analysis—enable MONTE.
- **.MEASURE** statement.

See “Monte Carlo Analysis” in the *HSPICE Simulation and Analysis User Guide*. For details about the syntax for these statements, see the *HSPICE Command Reference*.

## Operating Point

---

General Form	<b>.DC</b> MONTE=val
--------------	----------------------

---

## DC Sweep

---

General Form	<b>.DC</b> vin 1 5 .25 SWEEP MONTE=val
--------------	--

---

## AC Sweep

---

General Form	<b>.AC</b> dec 10 100 10meg SWEEP + MONTE=val
--------------	--

---

## TRAN Sweep

---

General Form	<b>.TRAN</b> 1n 10n SWEEP MONTE=val
--------------	-------------------------------------

---

## .PARAM Distribution Function Syntax

---

General Form	<b>.PARAM</b> xx=UNIF(nominal_val, + rel_variation <, multiplier>)
--------------	---

Or

	<b>.PARAM</b> xx=AUNIF(nominal_val, + abs_variation <,multiplier>)
--	---

Or	<b>.PARAM</b> xx=GAUSS(nominal_val, + rel_variation, sigma <,multiplier>)
Or	<b>.PARAM</b> xx=AGAUSS(nominal_val, + abs_variation, sigma <,multiplier>)
Or	<b>.PARAM</b> xx=LIMIT(nominal_val, + abs_variation)
abs_variation	AUNIF and AGAUSS vary the nominal_val by +/- abs_variation.
AGAUSS	Gaussian distribution function by using absolute variation.
AUNIF	Uniform distribution function by using absolute variation.
GAUSS	Gaussian distribution function by using relative variation.
LIMIT	Random limit distribution function by using absolute variation.
multiplier	If you do not specify a multiplier, the default is 1.
nominal_val	Nominal value for Monte Carlo analysis, and default value for all other analyses.
rel_variation	UNIF and GAUSS vary the nominal_val, by +/- (nominal_val · rel_variation).
sigma	Specifies abs_variation or rel_variation at the sigma level.
UNIF	Uniform distribution function by using relative variation.
xx	Distribution function calculates the value of this parameter.

---

## Optimizing Data

This chapter briefly describes how to optimize your design data.

---

## Analysis Statement (.DC, .TRAN, .AC) Syntax

General Form	<b>.DC</b> <DATA= <i>filename</i> > SWEEP + OPTIMIZE=OPT $_{xxx}$ + RESULTS= <i>ierr1</i> ... + <i>ierrn</i> MODEL= <i>optmod</i>
DATA	In-line file of parameter data to use in the optimization.

MODEL	The optimization reference name (also specified in the <b>.MODEL</b> optimization statement).
OPTIMIZE	Indicates the analysis is for optimization.
Or	<b>.AC</b> <DATA=filename> SWEEP + OPTIMIZE=OPTxxx + RESULTS=ierr1 ... + ierrn MODEL=optmod
Or	<b>.TRAN</b> <DATA=filename> SWEEP + OPTIMIZE=OPTxxx + RESULTS=ierr1 ... + ierrn MODEL=optmod
RESULTS	The measurement reference name (also specified in the <b>.MEASURE</b> optimization statement).

See **“.DC,” “.TRAN,”** or **“.AC”** in the *HSPICE Command Reference*.

---

## **.PARAM Statement Syntax**

General Form	<b>.PARAM</b> parameter=OPTxxx + (initial_guess, low_limit, upper_limit)
Or	<b>.PARAM</b> parameter=OPTxxx + (initial_guess, low_limit, upper_limit, + delta)
delta	The final parameter value is the initial guess $\pm$ ( $n$ -delta).
OPTxxx	Optimization parameter reference name. The associated optimization analysis references this name.
parameter	Parameter to be varied, the initial value estimate, the lower limit, and the upper limit allowed for the parameter.

See **“.PARAM”** in the *HSPICE Command Reference*.

---

## **.MODEL Statement Syntax**

General Form	<b>.MODEL</b> <i>mname</i> OPT <parameter = val + ...>
CENDIF	Point at which more accurate derivatives are required.
CLOSE	Initial estimate of how close parameter initial value estimates are to final solution.

CUT	Modifies CLOSE, depending on how successful the iterations toward the solution become.
DIFSIZ	Determines the increment change in a parameter value for gradient calculations ( $\Delta x = \text{DIFSIZ} \cdot \max(x, \text{PARMIN})$ ).
GRAD	Possible convergence when gradient of RESULTS function is less than GRAD.
ITROPT	Sets the maximum number of iterations.
LEVEL	Selects an optimizing algorithm.
MAX	Sets the upper limit on CLOSE.
mname	Model name.
PARMIN	Allows better control of incremental parameter changes during error calculations.
RELIN	Relative input parameter variation for convergence.
RELOUT	Relative output RESULTS function variance for convergence.

See “.MODEL” in the *HSPICE Command Reference*.

---

## Filters and Systems

To optimize filters and systems, use Pole Zero analysis. See “.PZ Statement— Pole/Zero Analysis” in the *HSPICE Applications Manual*.

---

## Laplace Transforms

See “Laplace Transform (LAPLACE) Function” and “Laplace Transform” in the *HSPICE Simulation and Analysis User Guide*.

## Transconductance H(s)

---

General Form	Gxxx n+ n- LAPLACE in+ in- k <sub>0</sub> , k <sub>1</sub> , ..., k <sub>n</sub> + / d <sub>0</sub> , d <sub>1</sub> , ..., d <sub>m</sub> <SCALE=val> <TC1=val> + <TC2=val> <M=val>
--------------	--

---

## Voltage Gain H(s)

---

General Form      Exxx n<sub>+</sub> n<sub>-</sub> LAPLACE in<sub>+</sub> in<sub>-</sub> k<sub>0</sub>, k<sub>1</sub>, ..., k<sub>n</sub>  
+ / d<sub>0</sub>, d<sub>1</sub>, ..., d<sub>m</sub> <SCALE=val> <TC1=val>  
+ <TC2=val>

---

---

## Output Format

For a detailed description of graphing with HSPLIT and GSI, see the *HSPICE Simulation and Analysis User Guide* "Graphing."

---

## Graphing Results in AvanWaves

The **.OPTION POST** must be placed in the HSPICE netlist input file.

- POST or POST=1 (default) creates a binary file.
- POST=2 creates an ASCII file, portable to all supported machines.

## Limiting the Size of the Graph Data File

The option PROBE limits the number of curves stored to those nodes specified in the HSPICE input file's **.PRINT**, **.PLOT**, **.OPTION PROBE**, and **.GRAPH** statements. The option INTERP (for transient analysis only) limits the number of points stored. The option INTERP preinterpolates the output to the interval specified on the **.TRAN** statement.

## Automatic Hardcopy During HSPICE Run

A **.GRAPH** statement automatically produces a hardcopy plot. A **.TITLE** statement placed before each **.GRAPH** statement sets the graph title. Otherwise, the simulation title is used. The POST option in conjunction with **.GRAPH** creates a graph data file.

## Starting AvanWaves—Command line

AvanWaves' command line definition is:

```
awaves [[-i][plot][-d] <path><design-name>  
+ [-c <config_name>]  
+ [laf(windows|openlook|motif)]
```

-i	Immediately opens the AvanWaves Command User Interface windows when you open AvanWaves.
-plot	Changes the plot mode to Continuous when you open AvanWaves. The default plot mode is Monotonic.
-d	The name of the design to be opened on invoking AvanWaves
-c	Specifies that a previously saved configuration for the current design is to be used upon the initialization of AvanWaves.
-laf [windows openlook  motif]	Specifies the window manager style to be used. The default is Motif.

## Setup Commands

Cmd	Default	Description
I	--	Name input file.
XMIN, XMAX, YMIN, YMAX	X=LIM Y=AUTO default 0.0	Set range defaults for all panels.
XSCAL	1.0	Scale for X axis.
YSCAL	1.0	Scale for Y axis.
XS, YS	LIN	Set x or y scale.
P	1	Set number of panels.
F	NONE	Set the frequency of symbols.
T	ON	Set/Toggle ticks.
M	NO	Monotonic. Set/Toggle for family of curves.
XG, YG	ON	Set/Toggle x or y grids.
D	--	Reinitialize all Setup menu values.

## Accessible Menus From Setup

G	Bring up the Graph window.
N	Bring up the Node window.
Q	Exit the program.

## Node Menu Prompts

- Panel            Each panel prompts for one x-axis parameter and any number of y-axis curves.
- X-axis           Any node may be chosen as the x-axis for a panel.
- Y-axis           Any listed node name or function, or algebraic expression can be entered at the y-axis prompt.

## Node Menu Commands

- \$P                Remove all curves in present panel.
- \$A                Remove all curves from all panels.
- \$Q                Exit the program.
- MORE            Display next/previous page of nodes.
- /BACK           These commands appear only when the node list spans more than one page.
- \$S                Bring up the Setup menu.

---

## AC Analysis

- \*R                Draw the Real component of the data.
- \*I                Draw the Imaginary component of the data.
- \*M                Calculate and draw the Magnitude.
- \*P                Calculate and draw the Phase.

## Graph Commands

- A, D             Add or Delete curves or expressions.
- X, Y             Change the view on some panels or all panels.
- Q                Exit the program.

## Accessible Menus from Graph Menu

- N                Bring up the Node window
- P                Bring up the Print menu
- S                Bring up the Setup menu

## Print Menu

The Print menu lists printers and /or plotters at your site on which you may create a hardcopy plot.



## Screensave Option

The SCREENSAVE function produces a file that can later be displayed on the terminal. The function is useful for making video slides.

---

## Print Commands

<CR>	Print with the default printer.
1...n-1	Print with one of printer options.
n	Save the screen into a preview file.

## .PRINT Statement

---

General Form     **.PRINT** antype ov1 <ov2 ... ovn>

---

See “.PRINT” in the *HSPICE Command Reference*.

## .PLOT Statement

---

General Form     **.PLOT** antype ov1 <(plo1,phi1)> . . .  
                  + <ovn> <(plo,n,phin)>

---

See “.PLOT” in the *HSPICE Command Reference*.

## .PROBE Statement

---

General Form     **.PROBE** antype ov1 ... <ovn>

---

See “.PROBE” in the *HSPICE Command Reference*.

## .GRAPH Statement

---

General Form     **.GRAPH** antype <MODEL = mname>  
                  + <unam1 = > ov1, <unam2 = > ov2, ...  
                  + <unamn = > ovn (plo,phi)

---

antype           Type of analysis for outputs: DC, AC, TRAN, NOISE, or DISTO. HSPICE RF does not support DISTO analysis.

mname           Plot model name referenced in **.GRAPH**.

ov1 ...ovn       Output variables to print or plot.

plo, phi ...     Lower and upper plot limits.

unam1...        User-defined output names.

See “.GRAPH” in the *HSPICE Command Reference*.

## **.MODEL Statement for .GRAPH**

---

General Form	<b>.MODEL</b> mname PLOT (pname1 = val1 + pname2 = val2...)
mname	Plot model name referenced in <b>.GRAPH</b> statement.
PLOT	Keyword for a <b>.GRAPH</b> statement model.
pname1=val1...	Each <b>.GRAPH</b> statement model includes several model parameters.

---

See “**.MODEL**” in the *HSPICE Command Reference*.

## **.MEASURE Statement: Rise, Fall, and Delay**

---

General Form	<b>.MEASURE</b> <DC   AC   TRAN> result + TRIG ... TARG ... <GOAL=val> + <MINVAL=val> <WEIGHT=val>
<DC AC TRAN>	Analysis type of the measurement. If omitted, assumes the last analysis mode requested.
GOAL	Desired measure value in optimization.
MEASURE	Specifies measurements.
MINVAL	If the absolute value of GOAL is less than MINVAL, then MINVAL replaces the GOAL value in the denominator of the ERRfun expression.
TRIG..., TARG ...	Identifies the beginning of trigger and target specifications, respectively.
WEIGHT	The calculated error is multiplied by the weight value.

---

See “**.MEASURE**” in the *HSPICE Command Reference*.

## **Trigger**

---

General Form	TRIG trig_var VAL=trig_val + <TD=time_delay> <CROSS=c> + <RISE=r> <FALL=f>
Or	TRIG AT=val
result	Name associated with the measured value in the HSPICE output.

---

## **Target**

---

General Form	TARG targ_var VAL = targ_val + <TD = time_delay> <CROSS = c   LAST> + <RISE = r   LAST> <FALL = f   LAST>
--------------	---

---

AT = val	Trigger specification. Determines where measurement takes place.
CROSS = c RISE = r FALL = f	Numbers indicate which occurrence of a CROSS, FALL, or RISE event to measure.
LAST	HSPICE or HSPICE RF measures when the last CROSS, FALL, or RISE event occurs.
TARG	Beginning of the target signal specification.
targ_val	Value of the targ_var, which increments the counter for crossings, rises, or falls, by one.
targ_var	Name of the output variable, at which HSPICE or HSPICE RF determines the propagation delay with respect to the trig_var.
time_delay	Amount of simulation time that must elapse, before HSPICE or HSPICE RF enables the measurement.
TRIG	Beginning of the trigger specification.
trig_val	Value of trig_var at which the counter for crossing, rises, or falls increments by one.
trig_var	Name of the output variable, that determines the logical beginning of a measurement.

## Average, RMS, MIN, MAX, and Peak to Peak

General Form	<b>.MEASURE</b> <DC   AC   TRAN> + <i>result func out_var</i> + <FROM = val> <TO = val> + <GOAL = val> + <MINVAL = val> <WEIGHT = val>
Or	<b>.MEASURE</b> < TRAN > <i>out_var</i> + <i>func var</i> FROM = <i>start</i> + TO = <i>end</i>
Or	<b>.MEASURE</b> DC results <MAX> + <DCMATCH_TOTAL   + DCMATCH(InstanceName)>
<DC AC TRAN>	Analysis type of the measurement. If omitted, HSPICE assumes the last analysis mode requested.
FROM	Initial value for the “func” calculation.

func	Type of the measure statement: AVG (average) MAX (maximum) MIN (minimum) PP (peak-to-peak) RMS (root mean squared) INTEG (integral)
GOAL	Desired <b>.MEASURE</b> value.
MINVAL	If the absolute value of GOAL is less than MINVAL, then MINVAL replaces the GOAL value in the denominator of the ERRfun expression.
out_var	Name of any output variable whose function the simulation measures.
result	Name of the measured value in the HSPICE output.
TO	End of the “func” calculation.
WEIGHT	Multiplies the calculated error, by the weight value.
start	Starting time of the measurement period.
end	Ending time of the measurement period.
DCMATCH (InstanceName)	.DCMATCH contribution from InstanceName.
DCMATCH_TOTAL	.DCMATCH total output variation.

## Equation Evaluation

---

General Form	<b>.MEASURE</b> <DC   AC   TRAN> result + PARAM = 'equation' <GOAL = val> + <MINVAL = val>
--------------	--

---

Or	<b>.MEASURE</b> TRAN varname + PARAM = 'expression'
----	--

---

See “**.MEASURE**” in the *HSPICE Command Reference*.

## ERROR Function

---

General Form	<b>.MEASURE</b> <DC   AC   TRAN> result + ERRfun meas_var calc_var + <MINVAL = val> <IGNORE   + YMIN = val> <YMAX = val> + <WEIGHT = val> <FROM = val> + <TO = val>
<DC AC TRAN>	Analysis type of the measurement. If omitted, assumes the last analysis mode requested.
calc_var	Name of the simulated output variable or parameter in the <b>.MEASURE</b> statement to compare with <i>meas_var</i> .
ERRfun	ERRfun indicates which error function to use: ERR, ERR1, ERR2, or ERR3.
FROM	Beginning of the ERRfun calculation.
IGNOR YMIN	If the absolute value of <i>meas_var</i> is less than the IGNOR value, the ERRfun calculation does not consider this point.
meas_var	Name of any output variable or parameter in the data statement.
MINVAL	If the absolute value of <i>meas_var</i> is less than MINVAL, then MINVAL replaces the <i>meas_var</i> value in the denominator of the ERRfun expression.
result	Name of measured result in the output.
TO	End of the ERRfun calculation.
WEIGHT	Multiplies the calculated error by the weight value.
YMAX	If the absolute value of <i>meas_var</i> is greater than the YMAX value, then the ERRfun calculation does not consider this point.

## Find and When Functions

General Form	<b>.MEASURE</b> <DC   AC   TRAN> result + WHEN out_var = val <TD = val> + < RISE = r   LAST > <FALL = f   + LAST > <CROSS = c   LAST > + <GOAL = val> <MINVAL = val> + <WEIGHT = val>
Or	<b>.MEASURE</b> <DC   AC   TRAN> result + WHEN out_var1 = out_var2 + < TD = val > < RISE = r   LAST > + <FALL = f   LAST > < CROSS = c   + LAST > <GOAL = val> + <MINVAL = val> <WEIGHT = val>
Or	<b>.MEASURE</b> <DC   AC   TRAN> result + FIND out_var1 WHEN out_var2 = val + < TD = val > < RISE = r   LAST > + <FALL = f   LAST > < CROSS = c   + LAST > <GOAL = val> + <MINVAL = val> <WEIGHT = val>
Or	<b>.MEASURE</b> <DC   AC   TRAN> result + FIND out_var1 WHEN + out_var2 = out_var3 <TD = val > + < RISE = r   LAST > <FALL = f   + LAST ><CROSS = c   LAST> + <GOAL = val> <MINVAL = val> + <WEIGHT = val>
Or	<b>.MEASURE</b> <DC   AC   TRAN> result + FIND out_var1 AT = val + <GOAL = val> <MINVAL = val> + <WEIGHT = val>
Or	<b>.MEASURE</b> DC result + FIND <DCMATCH_TOTAL   + DCMATCH(InstanceName)> AT = val
<DC   AC   TRAN>	Analysis type for the measurement. If omitted, HSPICE or HSPICE RF assumes the last analysis type requested.
CROSS = c RISE = r FALL = f	Numbers indicate which occurrence of a CROSS, FALL, or RISE event starts measuring.
AT = val	Trigger specification. Determines where measurement takes place.
FIND	Selects the FIND function.
GOAL	Desired <b>.MEASURE</b> value.
LAST	Starts measurement at the last CROSS, FALL, or RISE event.

MINVAL	If the absolute value of GOAL is less than MINVAL, then MINVAL replaces GOAL value in ERRfun expression denominator.
out_var(1,2,3)	Establish conditions to start measuring.
result	Name associated with a measured value in HSPICE or HSPICE RF output.
TD	Time at which measurement starts.
WEIGHT	Multiplies calculated error by weight value.
WHEN	Selects the WHEN function.
DCMATCH (InstanceName)	.DCMATCH contribution from InstanceName.
DCMATCH_TOTAL	.DCMATCH total output variation.

## **.DOUT Statement**

**.DOUT** *nd VTH* ( *time state*  
< *time state* > )

where:

- *nd* is the node name.
- *VTH* is the single voltage threshold.
- *time* is an absolute time-point.
- *state* is one of the following expected conditions of the *nd* node at the specified *time*:
  - 0      expect ZERO,LOW.
  - 1      expect ONE,HIGH.
  - else    Don't care.

**.DOUT** *nd VLO VHI* ( *time state*  
< *time state* > )

where:

- *nd* is the node name.
- *VLO* is the voltage of the logic low state.
- *VHI* is the voltage of the logic high state.
- *time* is an absolute time-point.

- *state* is one of the following expected conditions of the *nd* node at the specified *time*:
  - 0      expect ZERO,LOW.
  - 1      expect ONE,HIGH.
  - else    Don't care.

See “.DOUT” in the *HSPICE Command Reference*.

## .STIM Statement

You can use the **.STIM** statement to reuse the results (output) of one simulation as input stimuli in a new simulation.

The **.STIM** statement specifies:

- Expected stimulus (PWL Source, DATA CARD, or VEC FILE).
- Signals to transform.
- Independent variables.

One **.STIM** statement produces one corresponding output file.

## Syntax

Brackets [ ] enclose comments, which are optional.

```
.STIM <tran|ac|dc> PWL|DATA|VEC  
<filename=output_filename> ...
```

## DC and Transient Output

See “DC and Transient Output Variables” in the *HSPICE Simulation and Analysis User Guide*.

## Nodal Voltage

General Form	V(n1<,n2>)
n1, n2	Defines nodes between which the voltage difference (n1-n2) is to be printed/plotted.

See “Nodal Voltage Syntax” in the *HSPICE Simulation and Analysis User Guide*.



## Current: Voltage Sources

---

General Form	I(Vxxx)
Vxxx	Voltage source element name.

---

See “Current: Voltage Sources” in the *HSPICE Simulation and Analysis User Guide*.

## Current: Element Branches

---

General Form	In(Wwww)
or	Iall(Wwww)
n	Node position number in the element statement.
Wwww	Element name.
Iall (Www)	An alias just for diode, BJT, JFET, and MOSFET devices.

---

See “Current: Element Branches” in the *HSPICE User Guide*.

---

## Power Output

See “Power Output” in the *HSPICE Simulation and Analysis User Guide*.

## Print/Plot Power

---

General Form	<b>.PRINT</b> <DC TRAN> P(element_or_subcircuit_name) POWER
Or	<b>.PLOT</b> <DC TRAN> P(element_or_subcircuit_name) POWER
antype	Type of analysis for the specified plots: DC, AC, TRAN, NOISE, or DISTO.
ov1 ...	Output variables to plot.
plo1,phi1 ...	Lower and upper plot limits.

---

Power calculation is associated only with transient and DC sweep analyses. The **.MEASURE** statement may be used to compute the average, rms, minimum, maximum, and peak to peak value of the power. **POWER** invokes the total power dissipation output. See “**.PRINT**” or “**.PLOT**” in the *HSPICE Command Reference*.

---

## AC Analysis Output

See “AC Analysis Output Variables” in the *HSPICE Simulation and Analysis User Guide*.

### Nodal Voltage

---

General Form	Vz(n1<,n2>)
z	Voltage output type.
DB	Decibel
I	Imaginary Part
M	Magnitude
P	Phase
R	Real Part
T	Group Delay
n1, n2	Node names. If you omit n2, HSPICE assumes ground (node 0).

See “Nodal Voltage” in the *HSPICE Simulation and Analysis User Guide*.

### Current: Independent Voltage Sources

---

General Form	Iz(Vxxx)
Vxxx	Voltage source element name. If an independent power supply is within a subcircuit, then to access its current output, append a dot and the subcircuit name to the element name.
z	Current output type. See Nodal Voltage in the <i>HSPICE Simulation and Analysis User Guide</i> for specific output types.

See “Current: Independent Voltage Sources” in the *HSPICE Simulation and Analysis User Guide*.

## Current: Element Branches

---

General Form	Izn(Wwww)
n	Node position number in element statement.
Wwww	Element name. If the element is within a subcircuit, then to access its current output, append a dot and the subcircuit name to the element name.
z	Current output type. See Nodal Voltage of the <i>HSPICE Simulation and Analysis User Guide</i> for specific output types.

---

See “Current: Element Branches” in the *HSPICE Simulation and Analysis User Guide*.

## Group Time Delay t

---

General Form	VT(n1<,n2> or IT(Vxxx) or ITn(Wwww)
n1, n2	Node names. If you omit n2, HSPICE assumes ground (node 0).
Vxxx	Independent voltage source element name.
n	Node position number in element statement.
Wwww	Element name

---

Since there is discontinuity in phase each 360 degrees, the same discontinuity occurs in the  $T_d$ , even though  $T_d$  is continuous.

See “Group Time Delay” in the *HSPICE Simulation and Analysis User Guide*.

## Network Output

---

General Form	Xij (z), ZIN(z), ZOUT(z), YIN(z), YOUT(z)
ij	i and j can be 1 or 2. They identify the matrix parameter to print.
X	Specifies Z for impedance, Y for admittance, H for hybrid, or S for scattering parameters.
YIN	Input admittance.
YOUT	Output admittance.
z	Output type. If you omit z, HSPICE or HSPICE RF prints the magnitude of the output variable.

---

ZIN	Input impedance. For a one-port network, ZIN, Z11, and H11 are the same.
ZOUT	Output impedance.

See “Network” in the *HSPICE Simulation and Analysis User Guide*.

## Noise and Distortion

---

General Form	ovar <(z)>
--------------	------------

---

See “Nodal Voltage” on page 80 for specific output types.

ovar	Noise and distortion analysis parameter.
z	Output type (only for distortion).

See “Noise and Distortion” in the *HSPICE Simulation and Analysis User Guide*.

---

## Element Template Output

Use for DC, AC, or Transient Analysis.

---

General Form	Ename:Property
--------------	----------------

---

Ename	Name of the element.
Property	Property name of an element, such as a user-input parameter, state variable, stored charge, capacitance current, capacitance, or derivative of a variable.

See “Element Template Output” in the *HSPICE Simulation and Analysis User Guide*.

---

## Element Template Listings

### Resistor

Name	Alias	Description
G	LV1	Conductance at analysis temperature
R	LV2	Resistance at analysis temperature
TC1	LV3	First temperature coefficient
TC2	LV4	Second temperature coefficient

## Capacitor

<b>Name</b>	<b>Alias</b>	<b>Description</b>
CEFF	LV1	Computed effective capacitance
IC	LV2	Initial condition
Q	LX0	Charge stored in capacitor
CURR	LX1	Current flowing through capacitor
VOLT	LX2	Voltage across capacitor
–	LX3	Capacitance (not used in HSPICE releases after 95.3)

## Inductor

<b>Name</b>	<b>Alias</b>	<b>Description</b>
LEFF	LV1	Computed effective inductance
IC	LV2	Initial condition
FLUX	LX0	Flux in the inductor
VOLT	LX1	Voltage across inductor
CURR	LX2	Current flowing through inductor
–	LX4	Inductance (not used in HSPICE releases after 95.3)

## Mutual Inductor

<b>Name</b>	<b>Alias</b>	<b>Description</b>
K	LV1	Mutual inductance

## Voltage-Controlled Voltage Source (E Element)

<b>Name</b>	<b>Alias</b>	<b>Description</b>
VOLT	LX0	Source voltage
CURR	LX1	Current through source
CV	LX2	Controlling voltage
DV	LX3	Derivative of source voltage with respect to control current

## Current-Controlled Current Source (F Element)

Name	Alias	Description
CURR	LX0	Current through source
CI	LX1	Controlling current
DI	LX2	Derivative of source current with respect to control current

## Voltage-Controlled Current Source (G Element)

Name	Alias	Description
CURR	LX0	Current through the source, if VCCS
R	LX0	Resistance value, if VCR
C	LX0	Capacitance value, if VCCAP
CV	LX1	Controlling voltage
CQ	LX1	Capacitance charge, if VCCAP
DI	LX2	Derivative of source current with respect to control voltage
ICAP	LX2	Capacitance current, if VCCAP
VCAP	LX3	Voltage across capacitance, if VCCAP

## Current-Controlled Voltage Source (H Element)

Name	Alias	Description
VOLT	LX0	Source voltage
CURR	LX1	Source current
CI	LX2	Controlling current
DV	LX3	Derivative of source voltage with respect to control current

## Independent Voltage Source

Name	Alias	Description
VOLT	LV1	DC/transient voltage
VOLTM	LV2	AC voltage magnitude
VOLTP	LV3	AC voltage phase

## Independent Current Source

Name	Alias	Description
CURR	LV1	DC/transient current
CURRM	LV2	AC current magnitude
CURRP	LV3	AC current phase

## Diode

Name	Alias	Description
AREA	LV1	Diode area factor
AREAX	LV23	Area after scaling
IC	LV2	Initial voltage across diode
VD	LX0	Voltage across diode (VD), excluding RS (series resistance)
IDC	LX1	DC current through diode (ID), excluding RS. Total diode current is the sum of IDC and ICAP
GD	LX2	Equivalent conductance (GD)
QD	LX3	Charge of diode capacitor (QD)
ICAP	LX4	Current through diode capacitor. Total diode current is the sum of IDC and ICAP.
C	LX5	Total diode capacitance
PID	LX7	Photo current in diode

## BJT

Name	Alias	Description
AREA	LV1	Area factor
ICVBE	LV2	Initial condition for base-emitter voltage (VBE)
ICVCE	LV3	Initial condition for collector-emitter voltage (VCE)
MULT	LV4	Number of multiple BJTs
FT	LV5	FT (Unity gain bandwidth)
ISUB	LV6	Substrate current
GSUB	LV7	Substrate conductance
LOGIC	LV8	LOG 10 (IC)
LOGIB	LV9	LOG 10 (IB)
BETA	LV10	BETA
LOGBETAI	LV11	LOG 10 (BETA) current

<b>Name</b>	<b>Alias</b>	<b>Description</b>
ICTOL	LV12	Collector current tolerance
IBTOL	LV13	Base current tolerance
RB	LV14	Base resistance
GRE	LV15	Emitter conductance, 1/RE
GRC	LV16	Collector conductance, 1/RC
PIBC	LV18	Photo current, base-collector
PIBE	LV19	Photo current, base-emitter
VBE	LX0	VBE
VBC	LX1	Base-collector voltage (VBC)
CCO	LX2	Collector current (CCO)
CBO	LX3	Base current (CBO)
GPI	LX4	$g_{\pi} = {}^1ib / {}^1vbe$ , constant vbc
GU	LX5	$g_{\mu} = {}^1ib / {}^1vbc$ , constant vbe
GM	LX6	$g_m = {}^1ic / {}^1vbe + {}^1ic / {}^1vbe$ , constant vce
G0	LX7	$g_0 = {}^1ic / {}^1vce$ , constant vbe
QBE	LX8	Base-emitter charge (QBE)
CQBE	LX9	Base-emitter charge current (CQBE)
QBC	LX10	Base-collector charge (QBC)
CQBC	LX11	Base-collector charge current (CQBC)
QCS	LX12	Current-substrate charge (QCS)
CQCS	LX13	Current-substrate charge current (CQCS)
QBX	LX14	Base-internal base charge (QBX)
CQBX	LX15	Base-internal base charge current (CQBX)
GXO	LX16	1/Rbeff Internal conductance (GXO)
CEXBC	LX17	Base-collector equivalent current (CEXBC)
-	LX18	Base-collector conductance (GEQCBO) (not used in HSPICE releases after 95.3)
CAP_BE	LX19	cbe capacitance (CII)
CAP_IBC	LX20	cbc internal base-collector capacitance (Cμ)



<b>Name</b>	<b>Alias</b>	<b>Description</b>
CAP_SCB	LX21	csc substrate-collector capacitance for vertical transistors csb substrate-base capacitance for lateral transistors
CAP_XBC	LX22	cbcx external base-collector capacitance
CMCMO	LX23	$1/(TF*IBE) / vbc$
VSUB	LX24	Substrate voltage

## JFET

<b>Name</b>	<b>Alias</b>	<b>Description</b>
AREA	LV1	JFET area factor
VDS	LV2	Initial drain-source voltage
VGS	LV3	Initial gate-source voltage
PIGD	LV16	Photo current, gate-drain in JFET
PIGS	LV17	Photo current, gate-source in JFET
VGS	LX0	VGS
VGD	LX1	Gate-drain voltage (VGD)
CGSO	LX2	Gate-to-source (CGSO)
CDO	LX3	Drain current (CDO)
CGDO	LX4	Gate-to-drain current (CGDO)
GMO	LX5	Transconductance (GMO)
GDSO	LX6	Drain-source transconductance (GDSO)
GGSO	LX7	Gate-source transconductance (GGSO)
GGDO	LX8	Gate-drain transconductance (GGDO)
QGS	LX9	Gate-source charge (QGS)
CQGS	LX10	Gate-source charge current (CQGS)
QGD	LX11	Gate-drain charge (QGD)
CQGD	LX12	Gate-drain charge current (CQGD)
CAP_GS	LX13	Gate-source capacitance
CAP_GD	LX14	Gate-drain capacitance
-	LX15	Body-source voltage (not used in HSPICE releases after 95.3)
QDS	LX16	Drain-source charge (QDS)
CQDS	LX17	Drain-source charge current (CQDS)
GMBS	LX18	Drain-body (backgate) transconductance (GMBS)

## MOSFET

Name	Alias	Description
L	LV1	Channel length (L)
W	LV2	Channel width (W)
AD	LV3	Area of the drain diode (AD)
AS	LV4	Area of the source diode (AS)
ICVDS	LV5	Initial condition for drain-source voltage (VDS)
ICVGS	LV6	Initial condition for gate-source voltage (VGS)
ICVBS	LV7	Initial condition for bulk-source voltage (VBS)
–	LV8	Device polarity: 1 = forward, -1 = reverse (not used in HSPICE releases after 95.3)
VTH	LV9	Threshold voltage (bias dependent)
VDSAT	LV10	Saturation voltage (VDSAT)
PD	LV11	Drain diode periphery (PD)
PS	LV12	Source diode periphery (PS)
RDS	LV13	Drain resistance (squares) (RDS)
RSS	LV14	Source resistance (squares) (RSS)
XQC	LV15	Charge sharing coefficient (XQC)
GDEFF	LV16	Effective drain conductance (1/RDeff)
GSEFF	LV17	Effective source conductance (1/RSeff)
IDBS	LV18	Drain-bulk saturation current at -1 volt bias
ISBS	LV19	Source-bulk saturation current at -1 volt bias
VDBEFF	LV20	Effective drain bulk voltage
BETAEFF	LV21	BETA effective
GAMMAEFF	LV22	GAMMA effective
DELTAL	LV23	$\Delta L$ (MOS6 amount of channel length modulation) (only valid for LEVELs 1, 2, 3 and 6)
UBEFF	LV24	UB effective (only valid for LEVELs 1, 2, 3 and 6)
VG	LV25	VG drive (only valid for LEVELs 1, 2, 3 and 6)
VFBEFF	LV26	VFB effective

<b>Name</b>	<b>Alias</b>	<b>Description</b>
–	LV31	Drain current tolerance (not used in HSPICE releases after 95.3)
IDSTOL	LV32	Source diode current tolerance
IDDTOL	LV33	Drain diode current tolerance
COVLGS	LV36	Gate-source overlap capacitance
COVLGD	LV37	Gate-drain overlap capacitance
COVLGB	LV38	Gate-bulk overlap capacitance
VBS	LX1	Bulk-source voltage (VBS)
VGS	LX2	Gate-source voltage (VGS)
VDS	LX3	Drain-source voltage (VDS)
CDO	LX4	DC drain current (CDO)
CBSO	LX5	DC source-bulk diode current (CBSO)
CBDO	LX6	DC drain-bulk diode current (CBDO)
GMO	LX7	DC gate transconductance (GMO)
GDSO	LX8	DC drain-source conductance (GDSO)
GMBSO	LX9	DC substrate transconductance (GMBSO)
GBDO	LX10	Conductance of the drain diode (GBDO)
GBSO	LX11	Conductance of the source diode (GBSO)
<b>Meyer and Charge Conservation Model Parameters</b>		
QB	LX12	Bulk charge (QB)
CQB	LX13	Bulk charge current (CQB)
QG	LX14	Gate charge (QG)
CQG	LX15	Gate charge current (CQG)
QD	LX16	Channel charge (QD)
CQD	LX17	Channel charge current (CQD)
CGGBO	LX18	$\partial \text{GGBO} = \partial \text{Qg} / \partial \text{Vgt} = \text{CGS} + \text{CGD} + \text{CGB}$
CGDBO	LX19	$\partial \text{GDBO} = \partial \text{Qg} / \partial \text{Vdt}$ , (for Meyer $\text{CGD} = -\text{CGDBO}$ )
CGSBO	LX20	$\partial \text{GSBO} = \partial \text{Qg} / \partial \text{Vst}$ , (for Meyer $\text{CGS} = -\text{CGSBO}$ )
CBGBO	LX21	$\partial \text{BGBO} = \partial \text{Qb} / \partial \text{Vgt}$ , (for Meyer $\text{CGB} = -\text{CBGBO}$ )

Name	Alias	Description
CBDBO	LX22	CBDBO = $-dQ_b/dV_d$ intrinsic floating body-to-drain capacitance
CBSBO	LX23	CBSBO = $-dQ_b/dV_s$ intrinsic floating body-to-source capacitance
QBD	LX24	Drain-bulk charge (QBD)
–	LX25	Drain-bulk charge current (CQBD) (not used in HSPICE releases after 95.3)
QBS	LX26	Source-bulk charge (QBS)
–	LX27	Source-bulk charge current (CQBS) (not used in HSPICE releases after 95.3)
CAP_BS	LX28	Bulk-source capacitance
CAP_BD	LX29	Bulk-drain capacitance
CQS	LX31	Channel charge current (CQS)
CDGBO	LX32	$\partial DGBO = \partial Q_d/\partial V_{gb}$
CDDBO	LX33	$\partial DDBO = \partial Q_d/\partial V_{db}$
CDSBO	LX34	$\partial DSBO = \partial Q_d/\partial V_{sb}$

## Saturable Core Element

Name	Alias	Description
MU	LX0	Dynamic permeability ( $\mu$ ) Weber/(amp-turn-meter)
H	LX1	Magnetizing force (H) Ampere-turns/meter
B	LX2	Magnetic flux density (B) Webers/meter <sup>2</sup>

## Saturable Core Winding

Name	Alias	Description
LEFF	LV1	Effective winding inductance (Henry)
IC	LV2	Initial condition
FLUX	LX0	Flux through winding (Weber-turn)
VOLT	LX1	Voltage across winding (Volt)